




Manual I: Operating Instructions and Parts Reference

TC-15TM

Tree Chipper



PRODUCT INFORMATION



0500148 • OCTOBER 2016

DURATECH INDUSTRIES INTERNATIONAL INC.
PO Box 1940, JAMESTOWN, ND 58402-1940
TEL: (701) 252-4601 • FAX: (701) 252-0502
WWW.DURATECHINDUSTRIES.NET • WWW.HAYBUSTER.COM



 **DURATECH[®]**
Clearing the Way for a Better Tomorrow




TC-15TM

Tree Chipper

Operating Instructions and Parts Reference

DuraTech Industries International Inc. (DuraTech) has made every effort to assure that this manual completely and accurately describes the operation and maintenance of the TC-15TM Tree Chipper as of the date of publication. DuraTech reserves the right to make updates to the machine from time to time. Even in the event of such updates, you should still find this manual to be appropriate for the safe operation and maintenance of your unit.

This manual, as well as materials provided by component suppliers to DuraTech are all considered to be part of the information package. Every operator is required to read and understand these manuals, and they should be located within easy access for periodic review.

 **DURATECH[®]** is a registered trademark of Duratech Industries International, Inc. TC-15 is a trademark of Duratech Industries International, Inc.



 **DURATECH[®]**
Clearing the Way for a Better Tomorrow



Foreword

All personnel must read and understand before operating unit

DuraTech Industries International Inc. (DuraTech Industries) has made every effort to assure that this manual completely and accurately describes the operation and maintenance of this Industrial Grinder as of the date of publication. DuraTech Industries reserves the right to make updates to the machine from time to time. Even in the event of such updates, you should still find this manual to be appropriate for the safe operation and maintenance of your machine.

This manual, as well as materials provided by component suppliers to DuraTech Industries are all considered to be part of the information package. Every operator is required to read and understand these manuals. All manuals should be located within easy access for troubleshooting and periodic review.

Appropriate use of the unit

This Tree Chipper is designed to grind brush and tree branches no larger than 15 inches in diameter.

Operator protection

As with all machinery, care needs to be taken by the operator in order to insure the safety of the operator and those in the surrounding area.



WARNING: Operators and those observing the operation of the Industrial Grinder are required to wear head, eye, and ear protection. No loose clothing is allowed.



TABLE OF CONTENTS

TC-15 Tree Chipper Part 1: Operators Instructions.....1

Introduction 2

Purpose 2

Section 1: Safety..... 4

1.1 Safety-alert symbols 4

1.2 Operator - personal equipment 6

1.3 Machine safety labels 7

1.4 Shielding..... 9

1.5 Safety Review Section 9

1.6 Towing/road transport 13

Section 2: Introduction 14

2.1 Dry Clutch 14

2.2 Engine Control Panel 16

2.3 Other controls 17

Section 3: Operation 19

3.1 Pre-starting inspection instructions 19

3.2 Normal shut down procedure 19

3.3 Emergency stopping 20

3.4 Safety bumper bars 21

3.5 Normal Start up procedure 21

3.6 Rotating Discharge Spout..... 22

3.7 Engage Chipper Disc..... 23

3.8 Adjusting Engine Speed 23

3.9 Select Feed Speed (RPM) 23

3.10 Feed Forward/Reverse..... 23

3.11 Feeding Chipper without Auto Feed Height..... 23

3.12 Feeding Chipper with Auto Feed Height..... 24

3.13 Unplugging Procedure..... 24

3.14 Winch Operating Procedure 25

3.15 Transporting the TC-15 TREE CHIPPER..... 26

Section 4: Engine Maintenance..... 26



TABLE OF CONTENTS

Section 5: General Maintenance	27
5.1 Welding Procedure	27
5.2 Batteries.....	28
5.3 Hydraulic system.....	28
5.4 Clutch system	29
5.5 Axle, wheels, and tires.....	30
5.6 Lubrication	30
5.7 Wear parts.....	32
5.8 Checking and setting belt tension procedures	33
5.9 Spring tensioner for feed wheel	35
5.9A Torquing the feed wheel motor nut.....	35
5.10 Anvil adjustment	36
5.11 Changing knives	37
6.0 Troubleshooting the TC-15	38
6.1 General trouble shooting	38
6.2 Troubleshooting the feed control and electronic monitoring system (PLC) ...	39
Appendix A: WARRANTY.....	43
Appendix B: TC-15 Specifications	44
Part 2: Parts Reference	45
TRAILER ASSEMBLY	46
CAT ENGINE ASSEMBLY (FOR S.N. UP TO 0010)	48
CAT ENGINE ASSEMBLY - TIER 3 (FOR S.N. 0011 AND UP).....	50
DISC ASSEMBLY	52
INFEED ASSEMBLY VIEW 1.....	54
INFEED ASSEMBLY VIEW 1 - DETAILS A,B, & C	56
INFEED ASSEMBLY VIEW 2 (FOR S.N. UP TO 0010)	58
INFEED ASSEMBLY VIEW 2 (FOR S.N. 0011 AND UP).....	60
INFEED ASSEMBLY VIEW 3.....	62
INFEED ASSEMBLY VIEW 4.....	64
DISCHARGE ASSEMBLY VIEW 1	66
DISCHARGE ASSEMBLY VIEW 2	68



TABLE OF CONTENTS

RIGHT HAND CONTROL PANEL ASSEMBLY.....	70
LEFT HAND CONTROL PANEL ASSEMBLY.....	72
SHROUD ASSEMBLY VIEW 1.....	74
SHROUD ASSEMBLY VIEW 2.....	76
FUEL AND HYDRAULIC OIL TANK ASSEMBLY.....	78
GATHERING WINCH ASSEMBLY (OPTION).....	80
REMOTE RADIO (OPTION).....	81
4000403 MANIFOLD VALVE ASSEMBLY.....	82
MANIFOLD VALVE HYDRAULIC ASSEMBLY.....	84
HYDRAULIC TANK ASSEMBLY.....	86
CLUTCH HYDRAULICS.....	88
HYDRAULIC PUMP ASSEMBLY - CAT ENGINE.....	89
SEQUENCE VALVE ASSEMBLY.....	90
FEEDWHEEL HYDRAULIC MOTORS.....	91
DISCHARGE HYDRAULICS.....	92
HYDRAULIC CYLINDER ASSEMBLY.....	94
GATHERING WINCH HYDRAULICS (OPTION).....	96
5700991 HPTO WIRING HARNESS (FOR S.N. UP TO 0010).....	98
5701143 ENGINE CONTROL PANEL (FOR S.N. 0011 AND UP).....	99
5701024 MACHINE WIRING HARNESS.....	100
ELECTRICAL SCHEMATIC #1 (FOR S.N. UP TO 0010).....	101
ELECTRICAL SCHEMATIC #1 (FOR S.N. 0011 AND UP).....	102
ELECTRICAL SCHEMATIC #2.....	103
ELECTRICAL SCHEMATIC #3.....	104
DECALS.....	106
DECAL LOCATIONS.....	108
TC-12 Documentation Comment Form.....	111
APPENDIX C FOLDOUTS.....	113
5700912 MAIN HARNESS (For SN UP TO 0010).....	F1
5701143 MAIN HARNESS (For SN 0011 AND UP).....	F2



TC-15TM

TREE Chipper

Part 1:

Operating Instructions



Introduction

This TC-15 TREE CHIPPER is designed to chip trees and shrubs 15” diameter or less.

Purpose

Purpose of this owner’s manual is to explain maintenance requirements, safety and routine adjustments for most efficient operation of your TC-15 TREE CHIPPER. There is also a trouble shooting section that may help in case of problems in the field. Any information not covered in this manual may be obtained from your dealer.



SPECIAL NOTE: When reference is made as to front, rear, left hand or right hand of this machine, the reference is always made from standing at the rear of the machine and looking toward the hitch. Always use serial number and model number when referring to parts or problems. Please obtain your serial number and write it below for your future reference.

MODEL: _____ SERIAL NUMBER: _____



How to use this manual

Manual organization

This manual is organized into the following parts:

- **Part 1: Operating instructions** explain how to set up, use and maintain the TC-15 TREE CHIPPER.
- **Part 2: Parts reference** contains diagrams of each assembly with the number of each part identified. A key on the facing page contains a description of the part and the quantity used.

Operator responsibilities

- The operator is responsible for his own safety.
- The operator is responsible for the safety of others near the machine.
- Note the important safety information in the Foreword and in Section 1, “Safety.”
- Thoroughly review sections 1 through 3 which explain normal operation of the machine, and section 4, which explain maintenance requirements.
- Keep copies of manual in a readily accessible location for future reference.



Section 1: Safety

The safety of the operator is of great importance to DuraTech Industries. We have provided decals, shields and other safety features to aid in using your machine safely. In addition, we ask you to be a careful operator who will properly use and service DuraTech Industries equipment.



WARNING: FAILURE TO COMPLY WITH SAFETY INSTRUCTIONS THAT FOLLOW WITHIN THIS MANUAL COULD RESULT IN SEVERE PERSONAL INJURY OR DEATH. BEFORE ATTEMPTING TO OPERATE THIS MACHINE, CAREFULLY READ ALL INSTRUCTIONS CONTAINED WITHIN THIS MANUAL.

THIS MACHINE IS NOT TO BE USED FOR ANY PURPOSE OTHER THAN THOSE EXPLAINED IN THE OPERATOR'S MANUAL, ADVERTISING LITERATURE OR OTHER DURATECH INDUSTRIES WRITTEN MATERIAL PERTAINING TO THE TC-15 TREE CHIPPER.

1.1 Safety-alert symbols

Decals are illustrated in Part 2: Parts Reference.

The safety decals located on your machine contain important and useful information that will help you operate your equipment safely.

To assure that all decals remain in place and in good condition, follow the instructions below:

- Keep decals clean. Use soap and water- not mineral spirits, adhesive cleaners and other similar cleaners that will damage the decal.
- Replace all damaged or missing decals. When attaching decals, surface temperature of the machine must be at least 40 degrees F (5 degrees C). The surface must be also clean and dry.
- When replacing a machine component to which a decal is attached, be sure to also replace the decal.

DuraTech Industries uses industry accepted ANSI standards in labeling its products for safety and operational characteristics.



Safety-Alert Symbol

Read and recognize safety information. Be alert to the potential for personal injury when you see this safety-alert symbol.



DANGER: Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations, typically for machine components that, for functional purposes, cannot be guarded.



DANGER:
Signal word - White Lettering/Red Background
Safety Alert Symbol - White Triangle/Red Exclamation Point

WARNING: Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.



WARNING:
Signal word - Black Lettering/Orange Background
Safety Alert Symbol - Black Triangle/Orange Exclamation Point

CAUTION: Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



CAUTION:
Signal word - Black Lettering/Yellow Background
Safety Alert Symbol - Black Triangle/Yellow Exclamation Point

This manual uses the symbols to the right to denote important safety instructions and information.

The **DANGER**, **WARNING** and **CAUTION** symbols are used to denote conditions as stated in the text above. Furthermore, the text dealing with these situations is surrounded by a box with a white background, will begin with **DANGER**, **WARNING**, or **CAUTION**.

The **INFORMATION** symbol is used to denote important information or notes in regards to maintenance and use of the machine. The text for this information is surrounded by a box with a light grey background, and will begin with either **IMPORTANT** or **NOTE**.



	1. Yellow warning triangle/black graphical symbol, indicates what the hazard is. Hazard Identification
	2. Red circle-with-slash/black graphical symbol indicates a prohibited action to avoid the hazard. Prohibited Action
	3. Blue mandatory action circles/white graphical symbol - indicates an action to take to avoid the hazard. Mandatory Action



1.2 Operator - personal equipment

THE OPERATOR



NOTE: DO NOT OPERATE THIS MACHINE ALONE! Always have two operators present at all times.

Physical Condition

You must be in good physical condition and mental health and not under the influence of any substance (drugs, alcohol) which might impair vision, dexterity or judgment.

Do not operate a TC-15 TREE CHIPPER when you are fatigued. Be alert - If you get tired while operating your TC-15 TREE CHIPPER, take a break. Fatigue may result in loss of control. Working with any industrial equipment can be strenuous. If you have any condition that might be aggravated by strenuous work, check with your doctor before operating.

Proper Clothing



Clothing must be sturdy and snug-fitting, but allow complete freedom of movement. Avoid loosefitting jackets, scarfs, neckties, jewelry, flared or cuffed pants, unconfined long hair or anything that could become entangled with the machine.



Protect your head with a hard hat to reduce the risk of injury from flying debris.



Protect your hands with gloves when handling hammers, screens, etc.. . Heavy-duty, nonslip gloves improve your grip and protect your hands.



Good footing is most important. Wear sturdy boots with nonslip soles. Steel-toed safety boots are recommended.



To reduce the risk of injury to your eyes never operate a **TC-15 Tree Chipper** unless wearing goggles or properly fitted safety glasses with adequate top and side protection.




Tractor noise may damage your hearing. Always wear sound barriers (ear plugs or ear muffs) to protect your hearing. Continual and regular users should have their hearing checked regularly.




1.3 Machine safety labels





The safety decals located on your machine contain important information that will help you operate your equipment. Become familiar with the decals and their locations.

 **DANGER: ROTATING PARTS WITHIN CAN KILL OR DISMEMBER. WAIT FOR ALL MOVEMENT TO STOP BEFORE SERVICING, UNLOADING, OR INSPECTING MACHINE.**


 **DANGER**
ROTATING PARTS WITHIN CAN KILL OR DISMEMBER
WAIT FOR ALL MOVEMENT TO STOP BEFORE SERVICING,
UNCLOGGING OR INSPECTING MACHINE

6500082

 **DANGER: OBJECTS THROWN BY MACHINE**
DO NOT OPERATE WITHOUT WEARING SAFETY GLASSES AND A HARD HAT.
KEEP UNAUTHORIZED PERSONNEL OUT OF THE GRINDING AREA

<p> DANGER OBJECTS THROWN BY MACHINE Do not operate without wearing safety glasses and a hard hat. Keep all unauthorized personnel out of grinding area!</p>	<p> </p>	<p> PELIGRO OBJETOS LANZADOS POR LA MÁQUINA No opere esta máquina sin llevar puestos los anteojos de seguridad y el casco. Mantenga al personal no autorizado fuera del área de esmerilado!</p>
--	---	--

6500118

 **DANGER: THROWN OBJECT HAZARD**
KEEP AWAY

- TO PREVENT SERIOUS INJURY OR DEATH THROWN OBJECT:
- STAY AWAY FROM DISCHARGE AREA DURING OPERATION. KEEP OTHERS AWAY.
- DO NOT POINT DISCHARGE TOWARD PEOPLE, ANIMALS OR PROPERTY.


 **DANGER**



THROWN OBJECT HAZARD
KEEP AWAY

- To prevent serious injury or death from thrown object:
- Stay away from discharge area during operation. Keep others away.
- Do not point discharge toward people, animals or property.

6500221

 **DANGER: DO NOT OPEN WHEN CHIPPER IS TURNING.**

 **DANGER**

DO NOT OPEN
WHEN CHIPPER
IS TURNING

6500447



DANGER: ALWAYS USE THE CHIPPER DISC LOCK WHEN CHANGING CHIPPER KNIVES

⚠ DANGER

ALWAYS USE THE CHIPPER DISC LOCK WHEN CHANGING CHIPPER KNIVES

6500446



DANGER: DO NOT USE STARTING FLUID WITH ENGINE PREHEATER

⚠ DANGER


DO NOT USE STARTING FLUID WITH ENGINE PREHEATER

6500448



DANGER: NEVER REACH INSIDE INFEED CHUTE!

⚠ DANGER



NEVER REACH INSIDE INFEED CHUTE!

6500445




WARNING: FOR YOUR PROTECTION KEEP ALL SHIELDS IN PLACE AND SECURED WHILE MACHINE IS OPERATING. MOVING PARTS WITHIN CAN CAUSE SEVERE PERSONAL INJURY.

⚠ WARNING ⚠ ADVERTENCIA


FOR YOUR PROTECTION KEEP ALL SHIELDS IN PLACE AND SECURED WHILE MACHINE IS OPERATING. MOVING PARTS WITHIN CAN CAUSE SEVERE PERSONAL INJURY.

PARA ASEGURAR SU PROTECCION, MANTENGA TODOS LOS PROTECTORES EN SU LUGAR Y ASEGURADOS MIENTRAS LA MAQUINA ESTE OPERANDO. LAS PIEZAS MOVILES INTERNAS PUEDEN CAUSAR LESIONES PERSONALES GRAVES.

6500040



6500339



6500425

1.4 Shielding

Shields are installed for your protection. Keep them in place and replace damaged shields.

1.5 Safety Review Section

Before operating

Read and follow all instructions contained in:

- This TC-15 TREE CHIPPER operator’s manual
- Decals placed on the TC-15 TREE CHIPPER
- Check hydraulic oil level




NOTE: Additional copies of the above mentioned materials can be obtained from your dealer.


- Allow only responsible, properly instructed individuals to operate your machine. Carefully supervise inexperienced operators.
- Make sure the machine is in good operating condition and that all protective shields are in place and in proper working order. Replace damaged shields before operating.
- Be sure all bystanders and other workers are clear before starting the TC-15 TREE CHIPPER. Machine should be in a restricted area from people passing by and the area around the machine should be clear of all objects that can obstruct your movement when working with the machine.
- Machine should never be operated unless hooked to a towing vehicle.
- Make no modifications to the machine unless specifically recommended or requested by DuraTech Industries.
- Check periodically for breaks or unusual wear and make necessary repairs.
- **Do not** wear torn or loose clothing as they can get caught in moving machinery and tree branches. Items such as long hair, shirt sleeves and shirt need to be kept contained. Wear all personal protection equipment and follow all safety standards.

During operation

- Operators need to be located within easy reach of all feed controls and shut-off devices when the unit is running. Always be attentive and prepared to activate the devices.
- Always know the direction of the discharge chute before chipping. Never stand in front or direct the chute towards anyone or any thing.
- Never allow anyone to sit, stand, lay, climb or ride on the TC-15 TREE CHIPPER while it is running, operating, or in transit.
- Emergency stop switches (will shut down the engine when pressed)



Emergency stop
(left control panel)



Emergency stop
(right control panel)



Figure 1.1
Safety Bumper Bar



Safety bumper bar

- Feed forward will not operate if the safety bumper bars are not properly functioning. Consult your dealer if feed forward does not work after pressing reset.
- After the safety bumper bars are pressed the feed forward switch will not work until the reset on the engine control panel is pressed. Feed reverse will still function after the safety bumper is activated.
- Never reach into the infeed hopper area. The feedwheels are designed to pull trees and shrubs into the machine and could easily pull a person or extremities through much easier.
- Always stand to the side of the infeed hopper when inserting material. This allows you to turn away from the wood, and walk away, without passing through the material. (Figure 1.2)

Figure 1.2
Proper position for
feeding material into
the hopper





During service and maintenance

- Before working in or near the TC-15 TREE CHIPPER for any reason, including servicing, cleaning, unplugging or inspecting the machine, use the normal shut down procedures unless instructed differently in this manual.
- Never work on or near the TC-15 TREE CHIPPER unless engine is shut off.
- Check periodically and tighten any loose bolts or connections.
- Use only replacement parts that are recommended by DuraTech Industries.
- Use cylinder stop when cleaning or unplugging debris between feedwheels and chipping disc. (See Figure 1.3)

Figure 1.3
Cylinder Stop



- Use disc lock pin when servicing knives. (See Figure 1.4)

Figure 1.4
Disc Locking Pin





- Hydraulic fluid escaping under pressure can be invisible and have enough force to penetrate the skin. When searching for a suspected leak, use a piece of wood or cardboard rather than your hands. If injured, seek medical attention immediately to prevent serious infection or reaction.
- Do not operate the TC-15 TREE CHIPPER indoors.
- Make sure wheels are always blocked before running the chipper.

1.6 Towing/road transport

- Discharge spout needs to be in transport position pointed towards the hitch of the TC-15 TREE CHIPPER.
- Close and secure all doors and covers on the TC-15 TREE CHIPPER.
- Check tire pressure.
- Raise hitch to proper height and attach to towing vehicle securely.
- Locate jack and place in towing position.
- Hook safety chains to towing vehicle.
- Hook breakaway safety switch cable securely to towing vehicle.



Section 2: Introduction

2.1 Dry Clutch

The **HPTOTM Hydraulic Power Take off** is hydraulically actuated, enclosed dry clutch that requires no adjustment throughout its wear life. During a torque spike, the clutch will act as a torque limiter by slipping to absorb the shock load. The bearings in the clutch are grease for the life of the product.

A **Microprocessor Controller** provides remote push button controlled clutch engagement of the HPTO. The controller monitors clutch pressure, engine speed and equipment safety switch.

A **Hydraulic Manifold Assembly** controls the pressure required for clutch engagement. System components include a DC coil, a pressure regulating cartridge, and a pressure switch.

The pre-programmed setting of the controller determines how the HPTO unit will function during start up.

The “Power” LED illuminates to notify the operator that the controller is receiving switched power from the engine ignition switch.

The “Engine RPM” LED illuminates when the engine is running.

To engage the clutch, set the engine rpm below 1100 rpm, press and hold the “Engage/Disengage Button” for 3 seconds. Once the “Clutch Engage Symbol” illuminates, the reset button can be released. The controller will begin the engagement of the clutch and perform a series of “bumps” to bring the driven equipment up to engine speed.

Note that there is a safety switch that prevents the rotor from engaging when the disc cover is raised.

If the engine speed is above 1100 rpm while attempting to engage the clutch, the “Engine Over-speed Symbol” will illuminate. Reduce speed below 1100 rpm and the light will turn off.

To disengage the clutch, set engine speed below 1200 rpm and push the “Engage/Disengage Button”. The clutch will immediately disengage.




The controller will allow 3 failed clutch startup attempts in a row. After the 3rd failed clutch startup attempt, the controller will prevent the clutch from being engaged for 10 minutes.

There are three different conditions that are considered as “failed start attempts”. They are:

- The engine speed goes to zero and the engine stalls while the clutch is engaging.
- The operator attempts to increase engine speed while the clutch is engaging.
- The operator pushes the green engage/disengage button to disengage the clutch while the clutch is engaging.


If there is a pressure loss while the clutch is engaged, the controller will disengage the clutch and the “Oil Pressure Loss Symbol” will flash to indicate that there was a pressure loss while the clutch was engaged.






2.2 Engine Control Panel

The engine control panel is located on rear of the engine compartment. Controls and gauges on the control panel include the key switch, fuel gauge, safety bar reset, and the engine management screen and controls.



Left side control panel


Located on the left side of the machine, the switches control the spool, lift, spout, feed mode and engine off.





Right side control panel


Located on the right side of the machine, the switches control the spool, lift, spout, feed mode, rpm, engine off and a computer plug in.



2.3 Other controls

Battery disconnect switch

The battery disconnect switch is used to connect and disconnect the main battery ground to the machine. When the machine is not in use, it should be disconnected.






Governed Feed System

Governed feed system is intended to optimize engine horsepower and maintain consistent feed flow, it is always functioning. The hydraulic flow to the feedwheel drive mechanism is regulated proportionally to the engine speed. When the engine begins to lug down, the hydraulic oil flow is reduced which in turn slows down the feedwheel. The engine will only lug down to its optimum horsepower RPM and the feedwheel speed will be varied proportionally to keep the engine at this RPM. The result is a nearly constant load on the engine, which will maximize chipping efficiency. However, if the engine RPM goes below this preprogrammed RPM, the feedwheels will stop, reverse briefly, then when engine RPM recovers feed forward will reengage. If engine RPM does not recover in 10 seconds feed forward will not reengage until RPM's recover and feed forward switch is pressed.

Disc access safety switch

The TC-15 TREE CHIPPER is designed with a proximity switch assembled to the chipper hood. This safety feature is designed to shut down the engine if the chipper hood is not in a closed position. Engine will not start when switch and mating magnet are not aligned. The sensor has a yellow LED at the cable end of it that will light up when properly aligned. Proper clearance is 5mm and the sensor must be properly rotated to match the sensor with the polarity of the magnet. The magnet has an anti-rotation pin and a tamper proof screw.



Proximity switch
(LED light location)

Radio remote transmitter (Option)

The radio remote transmitter has two possible functions.

The choices are:

- 1) Feed roller Raise/Lower
- 2) Feed roller Fwd./Rev.
- 3) Winch In/Out



Radio remote transmitter

Function 1

Function 2



Section 3: Operation

To insure long life and economical operation, we highly recommend the operator of the TC-15 TREE CHIPPER be thoroughly instructed in the maintenance and operation of the machine. There is no substitute for a sound preventative maintenance program and a well trained operator.

Prior to starting the engine of the TC-15 TREE CHIPPER, we recommend the operator make a visual inspection of the unit. This can be done as the lubrication is being carried out. Any items that are worn, broken, missing, or needing adjustment must be serviced accordingly before operating the TC-15 TREE CHIPPER.

3.1 Pre-starting inspection instructions

Check the following:



Warning: Hydraulic fluid escaping under pressure can be invisible and have enough force to penetrate the skin. When searching for a suspected leak, use a piece of wood or cardboard rather than your hands. If injured, seek medical attention immediately to prevent serious infection or reaction.

- Check for loose bolts, worn or broken parts.
- Lug nuts for tightness.
- Condition of tire rims.
- Installation and condition of shields.
- Condition of decals.

3.2 Normal shut down procedure

Use this procedure before servicing, cleaning, inspecting, or transporting the TC-15 TREE CHIPPER.

Use a variation of this procedure only when instructed to so within this manual, or if an emergency requires it.

1. Reduce engine speed to idle.



Important: Whenever practical and consistent with good safety practices, allow the engine to run without being under load for a few minutes before shutting it off. This allows the engine temperature to decrease and equalize, which will increase engine life.

2. Disengage clutch.



Warning: The chipper disc will continue to turn for a short time after clutch has been disengaged.



3. Turn ignition key to the OFF position and remove the key.
4. Wait for the chipper disc to stop turning.




Note: Chipper disc rotation can be checked by looking at the end of the shaft on the side of the chipper housing.

3.3 Emergency stopping




Notice: Emergency shutoff controls are for **EMERGENCY** use **ONLY**. **DO NOT** use the emergency shutoff devices or controls for normal stopping procedure.

Left Control Panel



Emergency stop

Right Control Panel



Emergency stop



3.4 Safety bumper bars

The safety bumper bars are located on each side of the infeed. After these bumpers are pressed, the feed forward switch will not work until the reset button on the engine control panel is pressed. Feed reverse will still work if bumper is pressed. Feed forward will not function if either bumper bar is not working properly. If feed forward does not work after pressing reset button consult your dealer.



Safety bar

3.5 Normal Start up procedure



Note: Do not adjust the engine speed control during start-up. The electronic control Unit (ECU) will control the engine speed during start-up.

Starting a cold engine



Warning: If engine is equipped with an intake preheater, DO NOT use starting fluid.

When starting, both emergency stops must be pulled out. Rotor cover must be closed. By pressing the start toggle switch, the yellow LED rotor cover proximity switch will light. Turn engine key.

1. Disengage any equipment that is driven by the engine.
2. Turn the key switch to the RUN position. Leave the key switch in the RUN position for 20 seconds. (This allows glow plugs time to heat)



3. Turn the key switch to the START position in order to engage the electric starting motor and crank the engine.



Notice: Do not engage the starting motor when flywheel is turning. Do not start the engine under load.

If the engine fails to start within 30 seconds, release the starter switch or button and wait two minutes to allow the starting motor to cool before attempting to start the engine again.

4. Allow the key switch to return to the RUN position after the engine starts.
5. Repeat step 2 through 4 if the engine fails to start.

Starting a warm engine

1. Disengage any equipment that is driven by the engine.
2. Turn the key switch to the START position in order to engage the electric starting motor and crank the engine.



Notice: Do not engage the starting motor when flywheel is turning. Do not start the engine under load.

If the engine fails to start within 30 seconds, release the starter switch or button and wait two minutes to allow the starting motor to cool before attempting to start the engine again.

3. Allow the key switch to return to the RUN position after the engine starts.
4. Repeat step 2 and 3 if the engine fails to start.

3.6 Rotating Discharge Spout



Notice: Operator is responsible for insuring the spout is directed properly prior to engaging the chipper disc. Spout should “NEVER” be pointed toward the infeed area of the chipper. Spout should not be pointed at buildings, roadways, vehicles or anywhere flying debris may cause injury to others. Use traffic cones or tape off a perimeter to help alert others to flying debris hazard. Never point spout at surface of object or trees for example, that may deflect flying debris back at the chipper or operators.

1. With engine running, use the spout rotation switch on either control panel to adjust spout direction.
2. Adjust the spout deflector by pulling the handle down, then sliding toward end of spout to raise the deflector or toward chipper to lower the deflector.
3. Point spout toward the hitch for transport.



3.7 Engage Chipper Disc

1. Engine must be at low idle RPM to engage the clutch.
2. Press and hold clutch engagement button on the clutch control panel.
3. If the clutch control system fails to engage the clutch after the start sequence is complete, turn off the engine and inspect the disc housing and feed area for obstruction. Be sure that the disc is not rotating before servicing. (See 3.13 Unplugging Procedure)
4. Repeat step 2.

3.8 Adjusting Engine Speed

Use the up and down arrow keys on the engine management display to control the engine RPM. The engine will run at two preset engine RPM, Either 850 rpm (low idle) or 2400 rpm (high idle)

3.9 Select Feed Speed (RPM)

On the right control panel located at the right side of the chipper, the switch labeled RPM is used to set the feedroll speed and enables the auto height sensor if installed. Tree Mode is intended for chipping small log and brush with a faster feed RPM. Log Mode is intended for larger logs 6" diameter or larger. It has a slower feed RPM and enables the auto height sensor if equipped. Auto feed speed is always on and will stop when low engine RPM limit is reached, then reverse briefly to help the engine RPM recover.

3.10 Feed Forward/Reverse

Located on either control panel, the switch labeled FEED will start the feed wheels when pressing FWD or REV. If the light bars were contacted to stop the feed wheels, then auto feed reset must be pressed prior to FEED FWD. FEED Rev is momentary and requires the button to be held down to keep reverse engaged. If going from FEED FWD to FEED REV, then FEED REV must be pressed to turn off FEED FWD and pressed and held to engage FEED REV.

Engine must be at high idle and the chipper turning (clutch engaged) for FEED FWD to work.

3.11 Feeding Chipper without Auto Feed Height

1. Never enter feed hopper while engine is running.
2. Always stand to the side of the feed hopper while feeding the chipper to avoid being pulled into feed hopper by trailing branches, standing to the side of the feed hopper insures access to a safety bar.
3. Cut pieces into manageable sizes. Trying to feed logs too heavy or branches not easily handled by one operator increases the chances of strains and fatigue.
4. Load trees and limbs so the trunk end of the limb enters first with crotches and brush after. Once material has engaged the feed wheels and is advancing, step back from infeed hopper to avoid trailing limbs and branches.
5. When loading larger diameter logs, using the feed wheel lift to open the feed "throat" reduces the force required to push the log into the opposing feed wheels.



3.12 Feeding Chipper with Auto Feed Height

1. Select log RPM on the right control panel.
2. Never enter feed hopper while engine is running.
3. Always stand to the side of the feed hopper while feeding the chipper to avoid being pulled into feed hopper by trailing branches, standing to the side of the feed hopper insures access to a safety bar.
4. Cut pieces into manageable sizes. Trying to feed logs too heavy or branches not easily handled by one operator increases the chances of strains and fatigue.
5. Load trees and limbs so the trunk end of the limb enters first with crotches and brush after. Once material has engaged the feed wheels and is advancing, step back from infeed hopper to avoid trailing limbs and branches.
6. Load end of limb or log onto feed hopper and pass under height sensor. Height sensor will immediately open feed wheel throat to accept the material and release the top feed wheel to the spring applied down pressure to close the throat. The diameter of the material being fed will determine how high the top feed wheel will rise. Once material has engaged the feed wheels and is advancing step back from hopper to avoid trailing limbs and branches.

3.13 Unplugging Procedure

Always run the chipper at full engine speed. Dull knives can create chunks, and slivers, causing the engine to lug. This also contributes to the chipper plugging. Follow the steps below if your TC-15 TREE CHIPPER becomes plugged:

1. Follow the normal shut-down procedure.
2. Open the hinged portion of chipper hood when the disc is **NOT** turning.
3. Install disc/drum lock pin, and disconnect battery.
4. Open the hinged portion of chipper hood when the disc is **NOT** turning.
5. Open cleanout door on bottom of chipper housing.
6. Using a raking tool or gloved hands dig the chips out of the chipper housing.
7. If the discharge chute is plugged, use a raking tool to pull out the majority of the chips out of the open end of chute. Remove chute access located beneath curve in chute. Push/pull chips to clean as needed. Install discharge chute access cover.
8. **NEVER** turn the disc when someone is working inside the chipper housing. The chipper disc will turn hard then loose causing it to turn faster. Injury could result.
9. **ALWAYS** use a pry bar to turn the disc. **NEVER** turn by hand!
10. When the chipper disc turns freely, close and secure the chipper hood and close cleanout door. Engine will not start until this is done.
11. Follow normal start up procedure, engage clutch and throttle to full speed.
12. Insert small branch into feedwheel and check that it discharges properly then resume normal operations.




3.14 Winch Operating Procedure



DANGER: NEVER REACH INTO THE WINCH OR WINCH ROLLER AREA.

1. Disengage the winch clutch and pull cable to the material to be reeled in. Securely attach cable to the wood material that needs to be pulled to the chipper.
2. Make sure area is clear of workers and bystanders. Rotate clutch handle to rubber stop to engage winch clutch and make sure handle is in the lock position.
3. Using the SPOOL switch on the left or right control panel, pull the wood material to the chipper.
4. Unhook cable from the wood material and make sure it is completely reeled back in and out of the way.
5. Inspect winch cable daily for broken wires or frayed cable. Replace cable if it is damaged.



Choker sling



IMPORTANT: Always make sure that the cable is clear of the feedwheel. Severe damage can occur if the cable enters the chipper.

6. Engage the feedwheel and begin feeding the wood material.





3.15 Transporting the TC-15 TREE CHIPPER

1. Make sure towing vehicle hitch is properly equipped for the hitch of the TC-15 TREE CHIPPER.
2. Properly attach the chipper to the towing vehicle and install safety pins. Securely attach safety chains to the towing vehicle.
3. Check tire pressure and wheel rims for fatigue or loose bolts.
4. Hook up electrical connections and make sure all taillights and turn signals function properly.
5. Raise tongue jack to transport position.
6. Clean infeed of all debris.
7. Point discharge chute toward the hitch for transport.
8. Remove wheel blocks and check machine for any loose items that might get lost during transport.

Section 4: Engine Maintenance

Engine oil level, engine coolant level, air filters, and fan belt tension should be checked daily. All debris and combustible or ignitable material should be cleared from the engine compartment daily or more often as conditions warrant. When cleaning the engine compartment, pay particular attention to the top of the engine. Follow the engine manufacturer's recommendations for the replacement of parts and fluids, and follow the manufacturer's recommended maintenance schedule. Engine specifications should be found in the Operation and Maintenance manual for the engine.



Section 5: General Maintenance



Warning: Before servicing the TC-15 TREE CHIPPER, read the Service and Maintenance section of the Safety Instructions.

5.1 Welding Procedure

Welding on a machine that is equipped with an Electronic Engine.

Proper welding procedures are necessary in order to avoid damage to the computerized equipment. Computerized equipment includes but not limited to the following; the Engine Control Unit (ECU), HPTO Control Module and autofeed controller.

If at all possible, the component that is to be welded should be removed from the machine for welding. If removal of the component is not possible, the following procedure must be followed when welding on a machine that is equipped with electronic engine. This procedure is considered and safest and should provide minimum risk of electronic component damage.



Note: Do not ground the welder to electrical components such as the ECU or sensors. Improper grounding can also damage the drive train bearings or hydraulic components. Clamp the ground cable from the welder to the component that will be welded. Place the clamp as close as possible to the weld. This will help reduce the possibility of damage.

1. Stop the engine. Turn the battery disconnect switch to the OFF position.
2. Disconnect the negative battery cable from the battery.
3. Disconnect the connectors from the computerized equipment listed on the previous page. Move each harness to a position that will not allow the harness to accidentally move back and make contact with any of the connector pins.
4. Connect the welding ground cable directly to the part that will be welded. Place the ground cable as close as possible to the weld in order to reduce the possibility of welding current damage to the bearings, hydraulic components, electrical components, and ground straps.



Note: If the electrical/electronic components are used as a ground for the welder, or electrical/electronic components are located between the welder ground and the weld, current flow from the welder could damage the components.

5. Protect the wiring harness and hydraulic hoses from welding debris and spatter.
6. Use standard techniques to weld the materials.



5.2 Batteries

Check the condition of the batteries to insure that the electrolyte level is correct. Make sure that the terminals and cables are not corroded. Also make sure there is no arcing or grounding by the terminals.

The system uses two 12 volt batteries in a series for a 24 volt system.



Caution: Hydrogen gas given off by a battery is explosive. Keep sparks and flames away from the battery. Before connecting or disconnecting a battery charger, turn the charger off. Make last connection and first disconnection at a point away from the battery. Always connect the NEGATIVE (-) cable last and disconnect the NEGATIVE (-) cable first.

5.3 Hydraulic system



Caution: Lack of proper hydraulic oil level in the reservoir tank will cause system to heat under continuous running. Check the hydraulic oil level daily and replace as necessary.


The in-tank hydraulic oil filter should be changed after the first 10 hours of operation. Then change hydraulic oil and filters after 100 hours of operation. Thereafter, change hydraulic oil filters every 3 months or 400 hours of operation. Oil filter must be removed first before changing the oil or adding oil if the oil level is low. Maintain hydraulic oil level 7/8 full. Check hydraulic oil level daily. The filter housing has a filter restriction gage installed to monitor filter life.

Check the hydraulic oil regularly, and if the oil has a burnt smell or milky appearance, change immediately.





Hydraulic oil level
sight
glass



DuraTech Industries recommend using Cenex Qwicklift HTB if your machine has a Qwicklift decal on the hydraulic tank. Other acceptable fluids include Mobil 423, Farmland Super HTB, Conoco Hydroclear Power Tran Fluid, or similar fluids. If the hydraulic tank does not have a decal, then all the above fluid is acceptable.

5.4 Clutch system

Check all HPTO bolted connections and hydraulic connections every 500 hours.

Clutch is to be serviced and inspected after 5000 hours of operation – contact your dealer for details.



5.5 Axle, wheels, and tires

Tire Pressure

Set the tire pressure according to the manufacturer's specifications. The appropriate tire pressure can be found on the sidewall of the tire.

Brakes

The brakes are electrically activated drum style brakes that are actuated by an electromagnet. These braking systems are self-adjusting, but if manual adjustment is required, use the following procedure:

Brakes should be adjusted after the first 200 miles of operation when the brake shoes and drums have seated, at 3,000 mile intervals, or as the use and performance requires.

5.6 Lubrication

Use only high quality, #2 multi-purpose grease when lubricating the unit. Make sure all fittings and the nozzles or the grease applicators are clean before applying grease. If any grease fittings are missing, replace them immediately.

The TC-15 TREE CHIPPER has eight points to lubricate with a grease gun.

1. Chipper disc bearings - (2) places every 50 hrs.
2. Feedwheel bearings - (2) places every 50 hrs.
3. Discharge swivel - (2) places as needed
4. Wheel bearings – (2) places every 12 months

Discharge swivel chain- use a dry lubricant on it weekly

Figure 5.1
Chipper Disc Bearing
lubrication zerk (1 of 2)






Figure 5.2
Chipper Disc Bearing
lubrication zerk (2 of 2)

Chipper disc bearing




Figure 5.3
Feedwheel Bearings
lubrication zerks

Feedwheel bearings (1 of 2)

Feedwheel bearings (2 of 2)







Figure 5.4
Discharge Swivel
lubrication point



Discharge swivel

5.7 Wear parts

The feedwheel slide has friction pads and wear pads that will need to be replaced from time to time.

Figure 5.5
Feedwheel Slide Arm





5.8 Checking and setting belt tension procedures




NOTE: Check new belts as they stretch and must be adjusted several times in the first few hours of operation. Adjust after the first hour of operation and then every four hours until the belts quit stretching. If belt “chirps” or slips during clutch engagement sequence it is not tight enough.

General rules for tensioning:

1. Ideal tension is the lowest tension at which the belt will not slip under peak load conditions.
2. Check tension frequently during the first 24-48 hours of run-in operation.
3. Over tensioning shortens belt and bearing life.
4. Keep belts free of debris which may cause slipping.
5. Make V-Drive inspection on a periodic basis. Tension when slipping. Never apply belt dressing as this will damage the belt and cause early failure.
6. Make sure tension belt does not slip at start up.
7. Verify sheave alignment by laying a straight edge across the face of the sheaves. Alignment should be a $\frac{1}{4}$ ” or less for the given span.

Tensioning procedure:

1. Measure the span length, K.
2. At the center of the span (K) apply a force (perpendicular to the span) large enough to deflect the $\frac{1}{64}$ ”, for every inch of span length. For the TC-15 Chipper $K=28$ ”, so $28/64=7/16$ ” deflection.




3. Belt Deflection force for the TC-15 chipper with a new belt is 92 lbs at $7/16$ ” deflection and the normal value is at 64 lbs at $7/16$ ” deflection. If the force is between the values for normal tension and 1-1/2 times normal, then drive tension should be satisfactory. A force below the value for normal tension indicates an under-tensioned drive. If the force exceeds the value for 1-1/2 times normal tension, the drive is tighter than it needs to be.




Adjusting the belt tension on the TC-15 Chipper

1. Open belt shield.
2. Loosen all (6) bolts on the engine mount.



3. Using the “Tensioning Procedure”, adjust belt tension using the tensioner rod on the tension assembly.



4. Retighten the (6) engine mounting bolts.
5. Close belt cover.

Torques for sheave bolts

Disc side sheave (1400618) torque for bolts is 900 in-lbs (124.4 m-kg) and 720 in-lbs (99.5 m-kg) for engine side sheave (1400617).




5.9 Spring tensioner for feed wheel

The spring tensioners allow you to adjust the amount of tension on the top feedwheel.

1. Spring tension can be increased by tightening jam nuts on the bottom spring hook assembly.
2. Higher spring tension provides greater grip force.

Spring tensioner for feedwheel



5.9A Torquing the feed wheel motor nut

Torque tolerance for the feed wheel motor nut is 300-400 ft-lbs (41.5-55.3 m-kg). Torque to 300 ft-lbs (41.5 m-kg) then tighten until the pin holes line up with the castle nut.



5.10 Anvil adjustment



ALWAYS FOLLOW NORMAL SHUT DOWN PROCEDURE!


Locate the access hole on top of the feed housing in front of the bearing. Remove the three nuts and lift off cover.



Warning: Never turn disc while someone is adjusting the anvil. Disc should be turned by operator adjusting the anvil only! Operator adjusting anvil should only turn the disc in a clockwise direction to avoid limbs dismembered.

Checking and adjusting anvil to knife clearance

1. Follow the above safety features.
2. Check the anvil clearance by reaching into the access hole.
3. Using a feeler gauge, check the clearance between the knife anvil and the cutting edge of each knife. Anvil is set to the knife that is located closest to the anvil.
4. Inspect anvil edge for wear. Flip/rotate anvil if the cutting edge is unevenly worn or excessively rounded.
5. Loosen the six anvil bolts enough to move the anvil adjustment plate with the jam nuts.
6. Using the adjustment plate located by the anvil bolts, adjust the jam nuts to move the anvil to the desired position.
7. Retighten the anvil bolts and jam nuts.
8. Turning the disc clockwise, check the clearance on the knives making sure the closest knife is no closer than .050" and no further than 0.10". If anvil is not set close enough to knives, excessive knife wear will occur.





5.11 Changing knives

Knives should always be replaced in pairs. Pairs are determined by the amount of resharpening done to the knives. Reinstall with another knife of comparable usage. This helps to keep the disc balanced and it maintains chip quality.



ALWAYS FOLLOW NORMAL SHUT DOWN PROCEDURE!

1. With chipper properly shut down, open disc hood and insert disc lock pin through hole in chipper housing and hole in disc that allows access to knives to be changed.



Disc locking pin (in the locked position)

2. Loosen nuts and remove bolts and knife. Either rotate knife and replace, or insert new replacement knife, insert bolt and tighten to 125 ft-lbs (17.28 m-kg).
3. Always use same generation knives on the disc. Never install one or two resharpened knives with new knives. All knife surfaces should have the same clearance from the disc face. Failure to use like knives will cause premature knife and anvil wear.
4. Using anvil adjustment procedure from above, set anvil to 0.05-0.10" tolerance.
5. Replace hood and insert hood pin.



6.0 Troubleshooting the TC-15

6.1 General trouble shooting

Problem	Possible cause	Solution
Chipper disc will not turn.	<ol style="list-style-type: none"> 1. Obstruction in chipper housing 2. Check for seized chipper bearings 	<ol style="list-style-type: none"> 1. Check chipper housing and clean out 2. Lubricate or replace
Chipper disc wobbles.	<ol style="list-style-type: none"> 1. Disc hub loose 2. Bearing loose 3. Chipper bearings worn 4. Knife pocket or paddle is plugged with material 	<ol style="list-style-type: none"> 1. Re-torque to 1620 in-lbs 2. Re-torque to 270 ft-lbs 3. Replace 4. Unplug pockets
Chipper bearings running too hot.	<ol style="list-style-type: none"> 1. Improper lubrication 2. Belt too tight 3. Bearing lock collar may be loose 4. Bearings worn out 	<ol style="list-style-type: none"> 1. Purge bearings once a day with lithium grease 2. Set belt tension with tension gauge 3. Tighten bearing lock collar set screws 4. Replace
Discharge plugs or does not throw chips properly.	<ol style="list-style-type: none"> 1. Knives are dull or worn 2. Obstruction in discharge chute 	<ol style="list-style-type: none"> 1. Sharpen knives or replace with new ones 2. Remove access cover on chute to remove obstruction
Chipper knife hits anvil	<ol style="list-style-type: none"> 1. Anvil not set properly 2. Shaft misaligned 3. Disc is not properly set on shaft. 	<ol style="list-style-type: none"> 1. Follow anvil adjustment procedure. 2. Disc should have same clearance side to side. Adjust pillow block bearing. 3. Disc should have min. 11/16" clearance to housing on feed side. Slide disc on shaft
Chipper makes poor quality chips or does not feed properly.	<ol style="list-style-type: none"> 1. Knives lost their edge 2. Knife anvil worn or need adjustment. 3. Knives are at wrong angle 4. Not sufficient feedwheel down pressure 5. Material being chipped is small, dry or rotting 	<ol style="list-style-type: none"> 1. File, grind or replace knives 2. Rotate, repair or replace 3. Use DuraTech knives and sharpen to 30 degree angle 4. Increase spring tension 5. Type of material does not produce good quality chips
Feedwheel slow or stops when feeding.	<ol style="list-style-type: none"> 1. Dull knives 2. Relief valve is worn or dirty 3. Pump is worn 4. Motors are worn 5. Feedwheel springs too tight 	<ol style="list-style-type: none"> 1. Replace knives/Resharpen 2. Clean, rest or replace 3. Replace 4. Replace 5. Adjust
Feedwheel turns slowly or not at all.	<ol style="list-style-type: none"> 1. Relief valve stuck open 2. Worn hydraulic motor 3. Pump worn 4. Pinched hydraulic or damaged hydraulic hose 5. Feedwheel valve worn and leaking internally 6. Low hydraulic oil level 7. Plugged oil screen 8. binding such as worn bearing, etc, 9. Hydraulic oil is cold 10. Speed sensor is out of adjustment/not working or program set points are wrong 	<ol style="list-style-type: none"> 1. Clean or replace 2. Replace 3. Replace 4. Replace 5. Replace 6. Fill 7/8 full minimum 7. Replace 8. Repair 9. Should warm up while running 10. Turn sensor in until it contacts side of flywheel and turn out one turn.



6.2 Troubleshooting the feed control and electronic monitoring system (PLC)

General:

Tree chipper control to start and stop the feed roll based on engine speed and safety bar input. In log mode, ultrasonic sensor will adjust the feed roll height according to log size.

Details:

Feed Speed

- This output will drive the Feed Speed output proportionally to the engine RPM and the max speed will be set by the mode setting. There are two speed settings Log mode and Tree mode.

Feed Roller Forward

- Feed roller forward input will turn on feed roller forward output
- The safety bar, safety bar reset, and rpm will affect the forward direction

Feed Roller Reverse

- Feed roller reverse input will turn on feed roller reverse output to a fixed speed.

Feed Roll Raise

- Feed roll raise input will turn on feed roll raise output.

Clutch

- This input will tell the controller if the clutch is engaged. If the clutch is not engaged the feed forward cannot be turned on.

Log Mode

- When the log mode input is turned on the log height will be sensed by the Ultrasonic Sensor and raise the feed roll for a proportional amount of time based on the sensor output. After the time has elapsed the controller will bump the output for a number of times to hold the feed roll up. Then the output will be turned off. The Feed Roll height output will not be turned on until the feed position reaches the bottom Feed Roll Reset prox sensor.
- The feed roll output speed will be set to eeLogMode setting.

Tree Mode

- In brush mode the controller will not use the Ultrasonic Sensor and the Feed Roll feed position sensor.



- The feed roll output speed will be set to eeTreeMode setting.

Engine RPM

- The control will monitor the chipper speed, and based on when the engine rpm will proportionally control the feed roll speed until the speed drops to its programmable adjustable set point, will determine when the feed roller reverses.
- There will be an engine rpm set point and time of reversal setting for when the drop set point is reached.
- When the engine rpm starts to rise and reaches a programmable adjustable set point, the feed rollers will turn back on in the forward direction.
- If engine rpm does not reach the forward set point, feed roll stays in neutral
- This rpm will be taken off of the Engine flywheel (126 pulses per revolution)
- Low rpm fault
- When feed roll forward is on, and engine rpm is below its programmable adjustable set point for 10 seconds, the low rpm fault is true. If the rpm fault is true, the operator will have to momentarily reselect the direction desired with the switch.
- If engine rpm is below its programmable adjustable set point when the feed roll forward is pressed, the low rpm fault will be true. The engine rpm will have to be raised above the programmable adjustable set point and the feed roll forward switch will need to be pressed to start operation.

Safety Bar

- If safety bar is pressed or disconnected, the feed roller will stop.
- Feed roll will not go into forward position until Safety Bar Reset is pressed and the operator will have to momentarily press the forward direction with the feed forward switch.
- The safety bar will have no effect on the feed roller reverse switch; the feed roller will reverse at all times.

Safety Bar Reset

- Any time the safety bar is pressed, the safety bar reset will need to be pressed to reset the safety bar.
- If the safety bar is pressed, the operator must press the safety bar reset and then press the feed roll forward switch to continue forward movement of the feed rollers. If the safety bars have not reset, the feed rollers will not move forward.

Winch Override

- Any time the winch override input is turned on the feed roll will stop and the feed speed will = 100%.


LED Fault Lights

- The DCV710 has four Red/Green LEDs. Two are positioned on each side. The application can switch the meaning of the LEDs using the Programming Tool DVC710 IO configuration screen. Note the Power On period time can be changed as well. This is provided so that depending on how your controller is oriented in your vehicle the appropriate LEDs for your application can be seen.



LED Indicators

The DVC710 has four Red/Green LEDs, positioned on top of the module. They are labeled, Module Status, CAN Status, % Current and Error Status.



Operation

When a BIOS or application is being downloaded to the controller all LED's will be off. The Following is a list of the individual LED behaviors:

Module Status	
LED STATE	MEANING
Off	There is no power applied to the module.
On GREEN	The module is operating in a normal condition.
Flashing GREEN	Device is in standby state. May need servicing.
On RED	Module has an unrecoverable fault.
On YELLOW	System Disabled active
Flashing RED	Low Supply Voltage.



CAN Status	
LED STATE	MEANING
Off	There is no J1939 device (or other DVCs) in the project.
On GREEN	Communication established with another DVC module through DVC Devicenet.
Flashing GREEN	Waiting to establish communication with another DVC (i.e. DVC61) or J1939 Bus Enabled
On RED	The device has detected an error that has rendered it incapable of communicating on the network.
Flashing RED	The DVC Devicenet communication is in a timed-out state

% Current O/P	
LED STATE	MEANING
Off (Outputs Disabled) GRN (0-33%) YEL (34-66%) RED (66-100%)	
Flashing GREEN	PWM or High Side output Open circuit detected
Flashing RED	PWM or High Side output Short circuit detected

Error Status	
LED STATE	MEANING
Off	No errors
On RED	PWM1 Open or Short Detected
On GREEN	PWM2 Open or Short Detected
Flashing YELLOW	High Side Open or Short Detected
Multi Digit Blink Code	Application defined blink codes.

The Status LED

The programmer can send different single or multi digit blink codes to the status LED by using the application variable "Blinkcode". In the application code, the programmer would assign a 1, 2 or 3 digit non-zero value to the Blinkcode variable (i.e. Blinkcode = 501). The BIOS would then read this value, and then start flashing the Status LED to the assigned code, for example, in the example above (Blinkcode = 501) the Status LED would flash 5 times followed by a short pause then flash 10 times followed by a short pause then flash once then stop if no other code has been assigned. If a new code was assigned during the time that the code was flashing, there would be a longer pause before the next code began flashing. After the BIOS reads a blink code it will reset the Blinkcode variable to 0 allowing the application to test and see if the BIOS is ready for the next blink code assignment.

The following is an example of valid Blink Code assignments:

- Solid red = PWM1 Open or Short Detected (Feed Roll)
- Safety Fault - Error Light should blink 2 times
- RPM loss - Error light should blink 3 times
- Low Speed – Error light should blink 4 times



Appendix A: WARRANTY

DuraTech Industries International Inc. warrants to the original purchaser for one year from purchase date that this product will be free from defects in material and workmanship when used as intended and under normal maintenance and operating conditions. This warranty is limited to the replacement of any defective part or parts returned to our factory in Jamestown, N.D., within thirty (30) days of failure.

This warranty shall become void if in DuraTech Industries International, Inc.'s, judgment the machine has been subject to misuse, negligence, alterations, damaged by accident or lack of required normal maintenance, or if the product has been used for a purpose for which it was not designed.

All claims for warranty must be made through the dealer which originally sold the product and all warranty adjustments must be made through same.

This warranty does not apply to tires or bearings or any other trade accessories not manufactured by DuraTech Industries International Inc.'s. Buyer must rely solely on the existing warranty, if any, of these respective manufactures.

DuraTech Industries International Inc., shall **not** be held liable for damages of any kind, direct, contingent, or consequential to property under this warranty. DuraTech Industries International Inc., cannot be held liable for any damages resulting from causes beyond its control. DuraTech Industries International Inc., shall **not** be held liable under this warranty for loss of crops, or rental costs or any expense or loss for labor or supplies.

DuraTech Industries International Inc., reserves the right to make changes in material and/or designs of this product at any time without notice.



All other warranties made with respect to this product, either expressed or implied, are hereby disclaimed by DuraTech Industries International Inc.



Appendix B: TC-15 Specifications

General Specifications

Engine.....	CAT C4.4 122 HP (91 kW) or CAT C4.4 139 HP (103.7 kW)
Gross Weight	8,540 lbs. (3,874 kg)
Transport width	91" (231.1 cm)
Transport length	208" (528 cm)
Hitch	3" Pintle or 2-5/16" Ball
Tongue weight	1,140 lbs. (517.1 kg)
Axle	8,000 lb (3,629 kg) Torflex
Suspension	Torsional
Brakes	Electric
Electrical control system	24 V
Tires.....	10R 17.5 (16 ply)
Fuel capacity	40 gallon (152 L)
Hydraulic oil capacity	25 gallon (95 L)
Lights.....	Clearance and Directional
Transmission	PT Tech HPTO
Chipping capacity.....	15" (38.1 cm)
Infeed hopper opening.....	40" x 64" (102 cm x 163 cm)
Throat opening	15" x 23" (38 cm x 58 cm)
Disc size	48" (122 cm) diameter x 2" (5.08 cm)
Disc shaft size.....	3-15/16" (10 cm) diameter
Feed system.....	Hydraulic 2 drum
Number of knives.....	4, 2 slots
Size of knives	4-1/2" (11.5 cm) x 9-1/4" (23.5 cm) 3-bolt
Discharge system.....	360 degree, hydraulic rotation w/adjustable chip spout
Frame size	3" (7.6 cm) x 5" (12.7 cm) x 1/4 " (0.64 cm)
Safety Features	Breakaway Brake Switch, 2 E-Stop Switches,2 Infeed Hopper Light Bars, Disc Hood Closed Proximity Switch






TC-15TM

Tree Chipper

Part 2:

Parts Reference


TRAILER ASSEMBLY



TRAILER ASSEMBLY

ITEM	PART	QTY.	PART DESCRIPTION
1	2500975	1	AXLE\TOR\8KLB
2	2600866	2	TIRE\10R17.5\16PLY
3	2600867	2	WHL\8-BOLT\17.5X6.75\8x6.5
4	4700777	3	CLMP\HOSE\1/2
5	4800003	12	BOLT\HEX\3/8X1
6	4800098	4	BOLT\HEX\3/8X1-1/4\NC
7	4800146	1	BOLT\HEX\3/8X2
8	4800469	2	BOLT\HEX\3/4X1-3/4
9	4800573	3	BOLT\HEX\5/8X4-1/2\NF\GR8
10	4800633	2	BOLT\HEX\1X5-1/2\NC\GR5\PLT
11	4800639	4	SCR\HEX\SLOT\3/8X1\SELF-TAPPING
12	4900002	17	NUT\HEX\3/8\NC
13	4900004	2	NUT\HEX\3/4\NC
14	4900005	3	NUT\HEX\5/8\NC
15	5000012	2	WASH\LOCK\3/4
16	5000019	17	WASH\LOCK\3/8
17	5000053	2	WASH\LOCK\1
18	5700202	6	LAMP\GRMMT\2-1/2KITW\PLUG
19	5700725	1	SWITCH\BRAKE\BREAKAWAY
20	5700861	2	LAMP\CL\12VDC\2-1/2ROUND\RED\SEALED
21	5701015	4	LAMP\CL\12VDC\2-1/2ROUND\AMB\SEALED
22	6300046	1	JACK\10K\SINGLE SPEED\TC12
23	6300137	1	TENSIONER\ASSY\CHIPPER
24	6300162	2	LID\BOX\BATT\CHIP\ASSY
25	6300188	1	FRM\WELD\TC15
26	6300192	1	FNDR\R\CHPPR\TC15
27	6300193	1	FNDR\L\CHPPR\TC15
28	6300202	2	CHAIN\SAFETY\TC15
29	6300203	1	STEP\FRM\FNDR
30	6300214	1	HITCH\ASSY\ADJ
31	6300215	2	PL\COVER\HARN\TUBE
32	7500729	1	HITCH\PINTLE\3\BOLT-ON
33	7501183	3	CUSH\RBBR\1.87"ODX1.31"IDX390LB
34	7501523	8	GRMT\RBBR\1-3/8X1IDX1/8T
	6300187		TRAILER\ASSY\TC15
	NOT SHOWN		
	5700227	2	BATT\12VDC\GRP24
	5700275	4	TERMBATT\UNIV\MARINE\

CAT ENGINE ASSEMBLY (FOR S.N. UP TO 0010)



CAT ENGINE ASSEMBLY (FOR S.N. UP TO 0010)

ITEM	PART	QTY.	PART DESCRIPTION
1	0900148	1	ENG\CAT\C4.4\122HP\ATAAC
2	0900150	1	CLUTCH\HPTO8\CHIPPER
3	1400533	1	BUSH\QD\E\2-1/8
4	1400617	1	SHVE\5V-4\10.3\4/5V10.3-E
5	2000002	2	1" BEARING W/ LOCK COLLAR
6	2000703	4	2 HOLE FLANGETTE
7	4000290	1	VALVE\HYD\CART\2POS
8	4000434	1	NUT;O-RING\CART\HPTO
9	4000487	1	VALVE\CART\REDUCE\310P
10	4200124	1	PUMP\HYD\1.89CID\CASAPPA
11	4200139	1	VLV\SEQ\0-15GPM\PTTECH
12	4800082	6	BOLT\HEX\1/2X1-1/2
13	4800162	2	BOLT\HEX\5/16X2-1/4
14	4800925	4	BOLT\HEX\7/8X5
15	4900003	2	NUT\HEX\5/16\NC
16	4900022	4	NUT\HEX\7/8\NC
17	5000004	6	WASH\FLAT\1/2
18	5000022	2	WASH\LOCK\5/16
19	5000098	4	WASH\FLAT\7/8
20	5000106	4	WASH\LOCK\7/8
21	5700682	1	SNSR\MAG\HPTO12\3/8"DIA
22	5700957	1	SWITCH\PRESS\295\NO
23	5700970	1	VALVE\CLTCH\SOL\24\1/770\DEUTSCH
24	6200061	1	KEY\SQ\1/2X2-1/4
25	6300051	1	MNT\ENG\ASSY\TC12
26	6300059	1	GUARD\PLY\END\WELD
27	7500590	1	ENCL\OPS\8-1/2X11X1-5/8
28	7501062	4	CUSH\RBBR\3-1/2ODX2-7/8\>

6300003

ASSY\ENG\TC12


NOT SHOWN (WEAR PARTS)

1700237	1	BELT\5VX1120
4400129	1	FLTR\ELMT\AIR\C4.4
4400130	1	FLTR\FUEL\C4.4
4400131	1	FLTR\OIL\ENG\C4.4
4400132	1	FLTR\FUEL\WATER\C4.4
4400161	1	FLTR\ELMT\AIR\INNER\C4.4
5700854	1	SNSR\MAG\ENG\C4.4\2PIN\16MMDIA\DEUTSCH

NOT SHOWN

5700916	1	CNTRLLR\UNIT\DISPLAY\ADV3
5701020	1	CNTRLLR\UNIT\MSTR\BR72\HPTO8&10\
5701021	1	DISPLAY\CAN\J1939\C3-2500
5701082	1 SET	KEY\IGN\CHIPPERS\CONTROLS_INC
7500346	1	SAFETY CLIP
7500583	2	END FITTING\GAS SPRNG\
7500706	1	GAUGE\FUEL\24V\>
7501090	1	SPRNG\GAS\100LB\9416K22->
7501554	4	LATCH\DRAW\PANEL\ENG\CAT\C4.4

CAT ENGINE ASSEMBLY - TIER 3 (FOR S.N. 0011 AND UP)



CAT ENGINE ASSEMBLY - TIER 3 (FOR S.N. 0011 AND UP)

ITEM	PART	QTY.	PART DESCRIPTION
1	0900150	1	CLUTCH\HPTO8\CHIPPER
2	1400533	1	BUSH\QD\E\2-1/8
3	1400617	1	SHVE\5V-4\10.3\4/5V10.3-E
4	2000002	2	1" BEARING W/ LOCK COLLAR
5	2000703	4	2 HOLE FLANGETTE
6	4200139	1	VLV\SEQ\0-15GPM\PTTECH
7	4200201	1	Pump\HYD\89C\ICW\A-PAD\5/8" 9T\CASAPPA
8	4800153	4	BOLT\CRG\5/16X3/4\NC
9	4800162	2	BOLT\HEX\5/16X2-1/4
10	4800908	2	BOLT\CRG\1/2X1
11	4800925	4	BOLT\HEX\7/8X5
12	4900003	2	NUT\HEX\5/16\NC
13	4900022	4	NUT\HEX\7/8\NC
14	4900108	4	NUT\FLG\SERR\5/16\NC
15	4900110	6	NUT\FLG\SERR\5/8\NC
16	4900133	2	NUT\FLG\1/2\NC
17	4900142	1	NUT\TPLCK\5/16\NC
18	5000022	2	WASH\LOCK\5/16
19	5000098	4	WASH\FLAT\7/8
20	5000106	4	WASH\LOCK\7/8
21	6300212	1	GUARD\PLLY\END\WELD
22	6300229	1	MNT\ENG\CAT_C4.4\T3\CHIP
23	6300234	1	SHLD\CLUTCH\TC15
24	7500345	1	BALL STUD
25	7501062	4	CUSH\RBBR\3-1/2ODX2-7/8\>
26	0900214	1	ENG\CAT\C-4.4\129HP\ATAAC 24V

6300231

ENGIASSY\C4.4_T3\TC15


NOT SHOWN (WEAR PARTS)

1700237	1	BELT\5VX1120
4400129	1	FLTR\ELMT\AIR\C4.4
4400130	1	FLTR\FUEL\C4.4
4400131	1	FLTR\OIL\ENG\C4.4
4400132	1	FLTR\FUEL\WATER\C4.4
4400161	1	FLTR\ELMT\AIR\INNER\C4.4
5700854	1	SNSR\MAG\ENG\C4.4\2PIN\16MMDIA\DEUTSCH

NOT SHOWN

5700916	1	CNTRLLR\UNIT\DISPLAY\ADV3
5701020	1	CNTRLLR\UNIT\MSTR\BR72\HPTO8&10\
5701021	1	DISPLAY\CAN\J1939\C3-2500
5701082	1 SET	KEY\IGN\CHIPPERS\CONTROLS_INC
7500346	1	SAFETY CLIP
7500583	2	END FITTING\GAS SPRNG\
7500706	1	GAUGE\FUEL\24V\>
7501090	1	SPRNG\GAS\100LB\9416K22->


DISC ASSEMBLY



DISC ASSEMBLY

ITEM	PART	QTY.	PART DESCRIPTION
1	1400618	1	SHVE\5V-4\23.6\4\5V23.6-F
2	1400624	1	BUSH\R2\3
3	1400625	1	BUSH\QD-J\3-15\16
4	2000336	1	BRG\FLG\E\3"4BOLT
5	2000512	1	BRG\PB\3\2BOLT\E\DODGE
6	2900170	1	CAP\END\BRG\3\PB\E
7	4800567	3	BOLT\HEX\5\8X5\NC\GR8
8	4800628	16	BOLT\HEX\1\2X1-1\4\GR8\NC
9	4801204	12	SCR\CSK\ALN\1\2X3\NC
10	4900019	12	NUT\HEX\1\2\GR8\NC
11	5000003	3	WASH\LOCK\5\8
12	5000006	28	WASH\LOCK\1\2
13	6200024	1	KEY\SQ\3\4X4
14	6300007	1	SHAFT\DISC\CHIPPER
15	6300009	4	PADDLE\DISC\CHIPPER
16	6300166	1	DISC\HUB\ASSY\CHIPPER
17	7501510	4	KNIFE\CHIPPER\TC15
	6300165		DISC\SHAFT\ASSY\TC15


INFEED ASSEMBLY VIEW 1



INFEED ASSEMBLY VIEW 1

ITEM	PART	QTY.	PART DESCRIPTION
1	4000403	1	VLV\MANIFOLD\ASSY\CHIPPER
2	4800017	2	BOLT\HEX\3/4X3
3	4800018	4	BOLT\HEX\1/2X1-1/4
4	4800024	8	BOLT\HEX\1/4X3/4
5	4800098	4	BOLT\HEX\3/8X1-1/4\NC
6	4800113	2	SCR\FLNG\SERR\5/16X3/4\TP
7	4800115	4	BOLT\HEX\3/4X2-1/2
8	4800182	2	BOLT\HEX\5/16X3
9	4800201	6	BOLT\CRG\1/2X1-3/4\NC\GR5
10	4800224	2	BOLT\HEX\3/4X5
11	4800291	16	BOLT\CRG\1/4X3/4\NC
12	4800365	3	PIN\LYNCH\3/8X1-1/2W/U WIRE;KEEPER
13	4800404	8	SCR\BUT\ALN\1/4X1\NC
14	4800602	2	BOLT\HEX\1/4X1-1/4\NC
15	4801199	3	BOLT\HEX\5/8X1-1/4\GR8
16	4900001	3	NUT\HEX\1/2\NC
17	4900003	2	NUT\HEX\5/16\NC
18	4900004	2	NUT\HEX\3/4\NC
19	4900009	16	NUT\HEX\1/4\NC
20	4900014	6	NUT\PLCK\1/2\NC
21	4900040	16	NUT\FLG\SERR\1/4\NC
22	4900046	8	NUT\JAM\1/2\NC
23	5000001	4	WASH\FLAT\3/8
24	5000003	3	WASH\LOCK\5/8
25	5000006	7	WASH\LOCK\1/2
26	5000012	8	WASH\LOCK\3/4
27	5000019	4	WASH\LOCK\3/8
28	5000022	2	WASH\LOCK\5/16
29	5000024	20	WASH\LOCK\1/4
30	5000035	4	WASH\FLAT\1/4
31	5000113	6	WASH\FLAT\1/2\EXTRTHK\GR8
32	5700722	2	SNSR\IR\T\RSET\ASSY
33	5701009	1	LIGHTBAR\MINI\1073R
34	6300032	1	PIN\LATCH\HSG\ACCESS
35	6300036	1	ACCESS\HSG\DISC
36	6300062	1	SHIM\1/4\BRG\FEED
37	6300092	1	RAMP\SPOUT\INFEED
38	6300125	1	COVER\CLEANOUT\HSG\DISC\ASSY
39	6300158	2	SHLD\LEFT\LIGHTBAR
40	6300159	2	SHLD\RIGHT\LIGHTBAR
41	6300160	4	SHLD\EXT\LIGHTBAR
42	6300168	1	HSG\DISC\WELD
43	6300172	1	MNT\ANVIL
44	6300175	1	ANVIL\CHIPPER
45	6300177	1	GUIDE\ANVIL
46	6300178	1	COVER\FEED\HSG
47	6300179	1	MNT\VLV\TC15
48	6300196	1	DEFLECTOR/LIGHTBAR


INFEED ASSEMBLY VIEW 1 - DETAILS A, B, & C



INFEED ASSEMBLY VIEW 1 - DETAILS A, B, & C

ITEM	PART	QTY.	PART DESCRIPTION
1	4000403	1	VL\MANIFOLD\ASSY\CHIPPER
2	4800017	2	BOLT\HEX\3/4X3
3	4800018	4	BOLT\HEX\1/2X1-1/4
4	4800024	8	BOLT\HEX\1/4X3/4
5	4800098	4	BOLT\HEX\3/8X1-1/4\NC
6	4800113	2	SCR\FLNG\SERR\5/16X3/4\TP
7	4800115	4	BOLT\HEX\3/4X2-1/2
8	4800182	2	BOLT\HEX\5/16X3
9	4800201	6	BOLT\CRG\1/2X1-3/4\NC\GR5
10	4800224	2	BOLT\HEX\3/4X5
11	4800291	16	BOLT\CRG\1/4X3/4\NC
12	4800365	3	PIN\LYNCH\3/8X1-1/2W/U WIRE;KEEPER
13	4800404	8	SCR\BUT\ALN\1/4X1\NC
14	4800602	2	BOLT\HEX\1/4X1-1/4\NC
15	4801199	3	BOLT\HEX\5/8X1-1/4\GR8
16	4900001	3	NUT\HEX\1/2\NC
17	4900003	2	NUT\HEX\5/16\NC
18	4900004	2	NUT\HEX\3/4\NC
19	4900009	16	NUT\HEX\1/4\NC
20	4900014	6	NUT\PLCK\1/2\NC
21	4900040	16	NUT\FLG\SERR\1/4\NC
22	4900046	8	NUT\JAM\1/2\NC
23	5000001	4	WASH\FLAT\3/8
24	5000003	3	WASH\LOCK\5/8
25	5000006	7	WASH\LOCK\1/2
26	5000012	8	WASH\LOCK\3/4
27	5000019	4	WASH\LOCK\3/8
28	5000022	2	WASH\LOCK\5/16
29	5000024	20	WASH\LOCK\1/4
30	5000035	4	WASH\FLAT\1/4
31	5000113	6	WASH\FLAT\1/2\EXTRTHK\GR8
32	5700722	2	SNSR\IR\T\RSET\ASSY
33	5701009	1	LIGHTBAR\MINI\1073R
34	6300032	1	PIN\LATCH\HSG\ACCESS
35	6300036	1	ACCESS\HSG\DISC
36	6300062	1	SHIM\1/4\BRG\FEED
37	6300092	1	RAMP\SPOUT\INFEED
38	6300125	1	COVER\CLEANOUT\HSG\DISC\ASSY
39	6300158	2	SHLD\LEFT\LIGHTBAR
40	6300159	2	SHLD\RIGHT\LIGHTBAR
41	6300160	4	SHLD\EXT\LIGHTBAR
42	6300168	1	HSG\DISC\WELD
43	6300172	1	MNT\ANVIL
44	6300175	1	ANVIL\CHIPPER
45	6300177	1	GUIDE\ANVIL
46	6300178	1	COVER\FEED\HSG
47	6300179	1	MNT\VLV\TC15
48	6300196	1	DEFLECTOR/LIGHTBAR

INFEEED ASSEMBLY VIEW 2 (FOR S.N. UP TO 0010)




INFEEED ASSEMBLY VIEW 2 (FOR S.N. UP TO 0010)

ITEM	PART	QTY.	PART DESCRIPTION
1	3900047	1	MTR\HYD\39.6C\DELTA\TAPERED
2	4800024	2	BOLT\HEX\1/4X3/4
3	4800231	4	BOLT\HEX\1/2X3-3/4
4	4800365	4	PIN\LYNCH\3/8X1-1/2W/U WIRE;KEEPER
5	4800449	4	SCR\CAP\ALN\1/2X2-1/2\NC
6	4800486	6	BOLT\HEX\3/8X1-1/4\GR8\NC
7	4900030	2	NUT\NYLCK\3/8\NC
8	4900084	2	NUT\TPLCK\1/4\NC
9	5000006	4	WASH\LOCK\1/2
10	5000019	6	WASH\LOCK\3/8
11	5000114	4	WASH\FLAT\5/8\EXTRTHK\GR8
12	6300125	1	COVER\CLEANOUT\HSG\DISC\ASSY
13	6300140	1	DEFL\SPOUT\DISCH\ASSY
14	6300168	1	HSG\DISC\WELD
15	6300174	1	RLLR\FEED\WELD\BTTM
16	6300176	1	DOOR\BTTM\ACCESS
17	6300219	1	COUPLER\ROLLER\FEED
18	6300220	1	MNT\MTR\FEED\BTTM
19	6300221	1	COVER\BRG\FEED
20	6300223	4	SHIM\MTR\WHL
21	7501045	1	LATCH\ADJ\OTC\4" GRIP

NOT SHOWN

3900056	SEAL\KIT\MTR\3900047
4900188	NUT\SLOT\1"-20 UNEF-2B
6200095	KEY\SQ\5/16"X1" \HARDENED

INFEED ASSEMBLY VIEW 2 (FOR S.N. 0011 AND UP)




INFEED ASSEMBLY VIEW 2 (FOR S.N. 0011 AND UP)

ITEM	PART	QTY.	PART DESCRIPTION
1	3900047	1	MTR\HYD\39.6CI\DELTA\TAPERED
2	4800231	4	BOLT\HEX\1/2X3-3/4
3	4800365	8	PIN\LNCH\3/8X1-1/2W\KEEPER
4	4800449	4	SCR\CAP\ALN\1/2X2-1/2\NC
5	4800486	6	BOLT\HEX\3/8X1-1/4\GR8\NC
6	5000006	4	WASH\LOCK\1/2
7	5000019	6	WASH\LOCK\3/8
8	5000114	4	WASH\FLAT\5/8\EXTRTHK\GR8
9	5700202	2	LAMP\GRMMT\2-1/2KIT\W\PLUG
10	5700861	2	LAMP\CL\12VDC\2-1/2ROUND\RED\SEALED
11	5701155	4	REFL\RD\2.375"RED\ADHESIVE
12	6300140	1	DEFL\SPOUT\DISCH\ASSY
13	6300168	1	HSG\DISC\WELD
14	6300174	1	RLLR\FEED\WELD\BTTM
15	6300176	1	DOOR\BTTM\ACCESS
16	6300219	1	COUPLER\ROLLER\FEED
17	6300220	1	MNT\MTR\FEED\BTTM
18	6300221	1	COVER\BRG\FEED
19	6300223	4	SHIM\MTR\WHL
20	6300232	1	COVER\CLEANOUT\HSG\DISC
21	7501523	2	GRMT\RBBR\1-3/8X1IDX1/8T

NOT SHOWN

3900056	SEAL\KIT\MTR\3900047
4900188	NUT\SLOT\1"-20 UNEF-2B
6200095	KEY\SQ\5/16"X1"\HARDENED

INFEED ASSEMBLY VIEW 3




INFEED ASSEMBLY VIEW 3

ITEM	PART	QTY.	PART DESCRIPTION
1	3900047	1	MTR\HYD\39.6C\DELTA\TAPERED
2	4800251	4	BOLT\HEX\1/2X2-1/4\NC
3	4800449	4	SCR\CAP\ALN\1/2X2-1/2\NC
4	4800634	6	BOLT\HEX\1/2X1-1/2\GR8\NC
5	4800662	6	SCR\CAP\ALN\1/4X3/4\NC
6	5000006	10	WASH\LOCK\1/2
7	6300014	1	ARM\R\ROCKER\RLLR\FEED
8	6300102	1	MNT\MTR\FEED\SLIDE
9	6300168	1	HSG\DISC\WELD
10	6300218	1	RLLR\FEED\WELD
11	6300219	1	COUPLER\ROLLER\FEED
12	6300222	2	SHIM\MTR\WHL
13	7501351	2	PAD\WEAR\NY\9-1/2X1X3/4

NOT SHOWN

3900056	SEAL\KIT\MTR\3900047
4900188	NUT\SLOT\1"-20 UNEF-2B
6200095	KEY\SQ\5/16"X1"\HARDENED

INFEED ASSEMBLY VIEW 4




INFEED ASSEMBLY VIEW 4

ITEM	PART	QTY.	PART DESCRIPTION
1	2000337	2	BRG\FLG\CAST\4BOLT\2"
2	4100030	3	PIN 1" X 3-1/2" HYD. CYL.
3	4100284	1	CYL\HYD\2X16\1-1/4RD\WELDE
4	4800106	8	BOLT\HEX\5/8X1-1/2
5	4800107	6	PIN\HAIR\1/8(#9)
6	4800166	6	SCR\CSK\ALN\5/16X1\NC
7	4800546	1	BOLT\HEX\1X5\NC
8	4800662	12	SCR\CAP\ALN\1/4X3/4\NC
9	4900003	6	NUT\HEX\5/16\NC
10	4900104	2	NUT\JAM\3/4\NC
11	4900127	1	NUT\TPLCK\1\NC
12	5000003	8	WASH\LOCK\5/8
13	5000022	6	WASH\LOCK\5/16
14	5700680	1	SNSR\MAG
15	6100024	2	SPG\COMP\1.125OD\1.152WD\8"LONG
16	6100093	2	SPG\EXT\3.281DIAX.406 WIRE\22.25FREE LENGTH
17	6300011	1	ARM\L\ROCKER\RLLR\FEED
18	6300030	2	PAD\FRICTION\LIFT\RLLR
19	6300031	1	PAD\FRICTION\LIFT\FEED\RLLR
20	6300058	2	LNK\SPRG\CHPPR
21	6300094	2	RETAINER\SPG\TNSN\FEED\ROLL
22	6300168	1	HSG\DISC\WELD
23	6300180	1	LIFT\FEED\RLLR
24	7501351	4	PAD\WEAR\NY\9-1/2X1X3/4
25	7501356	1	SENSOR\ULTRASONIC\UGAGE_T_30

DISCHARGE ASSEMBLY VIEW 1

ITEM	PART	QTY.	PART DESCRIPTION
1	1000215	1	SPKT\60\B\10\1
2	1100062	1	CHAIN\60\CL
3	1100266	1	CHAIN\60 PITCH\81 LINK
4	3900032	1	MOTOR\HYD\22.6\H
5	4800003	4	BOLT\HEX\3\8X1
6	4800018	4	BOLT\HEX\1\2X1-1/4
7	4800053	1	BOLT\CRG\3\8X1\NC
8	4800082	6	BOLT\HEX\1\2X1-1/2
9	4800147	8	BOLT\HEX\5\16X7\8
10	4800222	1	BOLT\HEX\3\8X8
11	4800576	2	BOLT\HEX\5\8X9
12	4800913	4	BOLT\FLG\SERR\3\8X1\NC
13	4801236	1	PIN\LYNCH\1\4X1-9\16\ZN_PLT
14	4900001	10	NUT\HEX\1\2\NC
15	4900002	2	NUT\HEX\3\8\NC
16	4900030	1	NUT\NYLCK\3\8\NC
17	4900032	1	NUT\WING\3\8\NC
18	4900076	8	NUT\FLG\SERR\3\8\NC
19	4900141	2	NUT\TPLCK\5\8\GR8\NC
20	5000001	7	WASH\FLAT\3\8
21	5000002	2	WASH\FLAT\5\8
22	5000006	6	WASH\LOCK\1\2
23	5000019	6	WASH\LOCK\3\8
24	5000022	8	WASH\LOCK\5\16
25	5000113	8	WASH\FLAT\1\2\EXTRTHK\GR8
26	5700724	1	SW\MAG\CODED\1M_CABLE
27	5700730	1	ACTUATOR\CODED\MAGNET
28	6100010	1	SPRING\EXT\.55W X 1\20.D. X 3
29	6300032	1	PIN\LATCH\HSG\ACCESS
30	6300033	2	CLAMP\SPOUT\DISCH
31	6300035	1	DEFL\SPOUT\DISCH
32	6300044	1	PL\BRKT\MTR\CHUTE\ROT
33	6300050	1	SHLD\CHAIN\SPOUT
34	6300115	1	COVER\CLEANOUT\SPOUT
35	6300124	2	SHIM\CLAMP\SPOUT
36	6300125	1	COVER\CLEANOUT\HSG\DISC\ASSY
37	6300139	1	LATCH\DEFL\SPOUT
38	6300157	1	SPOUT\DISCH\CHIPPER
39	6300163	2	PL\ADJ\HINGE\HSG\ACCESS
40	6300170	1	HSG\ACCESS\CHIPPER
41	6300171	1	HSG\DISCH\CHIPPER
42	6300210	1	SHIELD\CHAIN\SPOUT\TC15
43	6300211	1	BRKT\SHIELD\CHAIN\SPOUT


DISCHARGE ASSEMBLY VIEW 2



DISCHARGE ASSEMBLY VIEW 2

ITEM	PART	QTY.	PART DESCRIPTION
1	1000215	1	SPKT\60\B\10\1
2	1100062	1	CHAIN\60\CL
3	1100266	1	CHAIN\60 PITCH\81 LINK
4	3900032	1	MOTOR\HYD\22.6\H
5	4800003	4	BOLT\HEX\3\8X1
6	4800018	4	BOLT\HEX\1\2X1-1/4
7	4800053	1	BOLT\CRG\3\8X1\NC
8	4800082	6	BOLT\HEX\1\2X1-1/2
9	4800147	8	BOLT\HEX\5\16X7\8
10	4800222	1	BOLT\HEX\3\8X8
11	4800576	2	BOLT\HEX\5\8X9
12	4800913	4	BOLT\FLG\SERR\3\8X1\NC
13	4801236	1	PIN\LYNCH\1\4X1-9\16\ZN_PLT
14	4900001	10	NUT\HEX\1\2\NC
15	4900002	2	NUT\HEX\3\8\NC
16	4900030	1	NUT\NYLCK\3\8\NC
17	4900032	1	NUT\WING\3\8\NC
18	4900076	8	NUT\FLG\SERR\3\8\NC
19	4900141	2	NUT\TPLCK\5\8\GR8\NC
20	5000001	7	WASH\FLAT\3\8
21	5000002	2	WASH\FLAT\5\8
22	5000006	6	WASH\LOCK\1\2
23	5000019	6	WASH\LOCK\3\8
24	5000022	8	WASH\LOCK\5\16
25	5000113	8	WASH\FLAT\1\2\EXTRTHK\GR8
26	5700724	1	SW\MAG\CODED\1M_CABLE
27	5700730	1	ACTUATOR\CODED\MAGNET
28	6100010	1	SPRING\EXT\.55W X 1\20.D. X 3
29	6300032	1	PIN\LATCH\HSG\ACCESS
30	6300033	2	CLAMP\SPOUT\DISCH
31	6300035	1	DEFL\SPOUT\DISCH
32	6300044	1	PL\BRKT\MTR\CHUTE\ROT
33	6300050	1	SHLD\CHAIN\SPOUT
34	6300115	1	COVER\CLEANOUT\SPOUT
35	6300124	2	SHIM\CLAMP\SPOUT
36	6300125	1	COVER\CLEANOUT\HSG\DISC\ASSY
37	6300139	1	LATCH\DEFL\SPOUT
38	6300157	1	SPOUT\DISCH\CHIPPER
39	6300163	2	PL\ADJ\HINGE\HSG\ACCESS
40	6300170	1	HSG\ACCESS\CHIPPER
41	6300171	1	HSG\DISCH\CHIPPER
42	6300210	1	SHIELD\CHAIN\SPOUT\TC15
43	6300211	1	BRKT\SHIELD\CHAIN\SPOUT

RIGHT HAND CONTROL PANEL ASSEMBLY




RIGHT HAND CONTROL

RIGHT HAND CONTROL PANEL ASSEMBLY

ITEM	PART	QTY.	PART DESCRIPTION
1	4800301	12	SCR\FLNG\SERR\1/4X3/4
2	4800463	2	SCR\RD\SLOT\#8X3/4\NC
3	4801225	8	SCR\RD\SLOT\#8-32X1/2\NC
4	4900040	12	NUT\FLG\SERR\1/4\NC
5	4900096	10	NUT\HEX\#8\NC
6	5000092	5	WASH\LOCK\#8
7	5700028	2	SWITCH\MAINT\PB\RED\MUSH
8	5700328	9	SWITCH\RCKR\MNT\PNL\SNGL
9	5700542	8	SWITCH\RCKR\DPDT\24VUNLIT\15A\MOMNTRY\W/RASED BRCKT
10	5700545	1	SWITCH\RCKR\DPST\24V\2LIT\15A\LATCH\W/RAISED BRACKET
11	5700722	2	SNSR\IR\T\RSET\ASSY
12	6300105	2	BACK\PANEL\CNTRL
13	7500606	2	LATCH\35-M\AUSTIN
14	7500756	2	BMPR\RBBR\1-1/32X5/8
	6300190		PANEL\CNTRL\SUB-WELD\LEFT
	6300191		PANEL\CNTRL\SUB-WELD\RIGHT

LEFT HAND CONTROL PANEL ASSEMBLY




LEFT HAND CONTROL PANEL

LEFT HAND CONTROL PANEL ASSEMBLY

ITEM	PART	QTY.	PART DESCRIPTION
1	4800301	12	SCR\FLNG\SERR\1/4X3/4
2	4800463	2	SCR\RD\SLOT\#8X3/4\NC
3	4801225	8	SCR\RD\SLOT\#8-32X1/2\NC
4	4900040	12	NUT\FLG\SERR\1/4\NC
5	4900096	10	NUT\HEX\#8\NC
6	5000092	5	WASH\LOCK\#8
7	5700028	2	SWITCH\MAINT\PB\RED\MUSH
8	5700328	9	SWITCH\RCKR\MNT\PNL\SNGL
9	5700542	8	SWITCH\RCKR\DPDT\24VUNLIT\15A\MOMNTRY\W/RAISED BRCKT
10	5700545	1	SWITCH\RCKR\DPST\24V\2LIT\15A\LATCH\W/RAISED BRACKET
11	5700722	2	SNSR\IR\T\RSET\ASSY
12	6300105	2	BACK\PANEL\CNTRL
13	7500606	2	LATCH\35-M\AUSTIN
14	7500756	2	BMPR\RBBR\1-1/32X5/8
	6300190		PANEL\CNTRL\SUB-WELD\LEFT
	6300191		PANEL\CNTRL\SUB-WELD\RIGHT


SHROUD ASSEMBLY VIEW 1



SHROUD ASSEMBLY VIEW 1

ITEM	PART	QTY.	PART DESCRIPTION
1	4800045	1	PIN\CLEVIS\3/4X2-1/2
2	4800056	1	PIN\HAIR\3/16(#3)
3	4800098	4	BOLT\HEX\3/8X1-1/4\NC
4	4800277	2	BOLT\HEX\1/4X1
5	4800301	10	SCR\FLNG\SERR\1/4X3/4
6	4800503	2	BOLT\HEX\1/4X5/8\NC
7	4800913	19	BOLT\FLG\SERR\3/8X1\NC
8	4800928	6	BOLT\FLG\SERR\1/2X1-1/4\NC
9	4801199	6	BOLT\HEX\5/8X1-1/4\GR8
10	4900009	4	NUT\HEX\1/4\NC
11	4900040	10	NUT\FLG\SERR\1/4\NC
12	4900076	23	NUT\FLG\SERR\3/8\NC
13	4900133	7	NUT\FLG\1/2\NC
14	5000001	4	WASH\FLAT\3/8
15	5000003	6	WASH\LOCK\5/8
16	5000019	4	WASH\LOCK\3/8
17	5000024	4	WASH\LOCK\1/4
18	5700090	2	CLAMP\CUSH\HD\#16\1"
19	5700202	2	LAMP\GRMMT\2-1/2KITW/PLUG
20	5700539	4	LAMP\GRMMT\4-1/2
21	5700723	1	PLC\DVC710
22	5700818	1	LAMP\LIC\KIT
23	5700860	4	LAMP\TAIL\12VDC\4-1/2RD
24	5700861	2	LAMP\CL\12VDC\2-1/2ROUND\RED\SEALED
25	6300125	1	COVER\CLEANOUT\HSG\DISC\ASSY
26	6300145	1	STOP\CYL\CHIPPER
27	6300153	1	COVER\WINCH\HOOD
28	6300168	1	HSG\DISC\WELD
29	6300184	1	HOOD\RH\TAIL\CHIPPER
30	6300185	1	HOOD\LH\TAIL\CHIPPER
31	6300195	2	COVER\LIGHT\TAIL\R
32	6300197	1	SHIELD\R\TC-15
33	6300199	1	SHIELD\L\TC15
34	6300207	1	BRKT\COVER\VLV
35	6300208	1	SHIELD\TOP\L
36	6300209	1	SHIELD\TOP\R


SHROUD ASSEMBLY VIEW 2



SHROUD ASSEMBLY VIEW 2

ITEM	PART	QTY.	PART DESCRIPTION
1	4800045	1	PIN\CLEVIS\3/4X2-1/2
2	4800056	1	PIN\HAIR\3/16(#3)
3	4800098	4	BOLT\HEX\3/8X1-1/4\NC
4	4800277	2	BOLT\HEX\1/4X1
5	4800301	10	SCR\FLNG\SERR\1/4X3/4
6	4800503	2	BOLT\HEX\1/4X5/8\NC
7	4800913	19	BOLT\FLG\SERR\3/8X1\NC
8	4800928	6	BOLT\FLG\SERR\1/2X1-1/4\NC
9	4801199	6	BOLT\HEX\5/8X1-1/4\GR8
10	4900009	4	NUT\HEX\1/4\NC
11	4900040	10	NUT\FLG\SERR\1/4\NC
12	4900076	23	NUT\FLG\SERR\3/8\NC
13	4900133	7	NUT\FLG\1/2\NC
14	5000001	4	WASH\FLAT\3/8
15	5000003	6	WASH\LOCK\5/8
16	5000019	4	WASH\LOCK\3/8
17	5000024	4	WASH\LOCK\1/4
18	5700090	2	CLAMP\CUSH\HD\#16\1"
19	5700202	2	LAMP\GRMMT\2-1/2KITW/PLUG
20	5700539	4	LAMP\GRMMT\4-1/2
21	5700723	1	PLC\DVC710
22	5700818	1	LAMP\LIC\KIT
23	5700860	4	LAMP\TAIL\12VDC\4-1/2RD
24	5700861	2	LAMP\CL\12VDC\2-1/2ROUND\RED\SEALED
25	6300125	1	COVER\CLEANOUT\HSG\DISC\ASSY
26	6300145	1	STOP\CYL\CHIPPER
27	6300153	1	COVER\WINCH\HOOD
28	6300168	1	HSG\DISC\WELD
29	6300184	1	HOOD\RH\TAIL\CHIPPER
30	6300185	1	HOOD\LH\TAIL\CHIPPER
31	6300195	2	COVER\LIGHT\TAIL\R
32	6300197	1	SHIELD\R\TC-15
33	6300199	1	SHIELD\L\TC15
34	6300207	1	BRKT\COVER\VLV
35	6300208	1	SHIELD\TOP\L
36	6300209	1	SHIELD\TOP\R

FUEL AND HYDRAULIC OIL TANK ASSEMBLY



FUEL AND HYDRAULIC OIL TANK ASSEMBLY

ITEM	PART	QTY.	PART DESCRIPTION
1	3800279	1	FTG\1-1/16MORX1-1/16MJIC\90
2	3800453	1	FTG\3/4MORX9/16MJIC\90
3	3800490	1	FTG\3/4MOR\PLUG\HEX
4	3800534	1	FTG\1-5/16MORX1-1/16MJIC\90
5	3800537	1	FTG\3/4MORX3/4MJIC\90
6	3800847	1	FTG\7/8MOR\PLUG\HEX
7	4400111	1	FLTR\SCRN\1-5/8MORX1-1-16FOR\10GPM
8	4400112	1	FLTR\HYD\RET\15GPM\TTF
9	4704786	1	GUARD\SENSOR\TANK\FUEL
10	4704787	1	CVR\SENSOR\TANK\FUEL
11	4800503	2	BOLT\HEX\1/4X5/8\NC
12	4800592	3	BOLT\HEX\1/2X3-1/4
13	4900001	3	NUT\HEX\1/2\NC
14	4900009	2	NUT\HEX\1/4\NC
15	5000006	3	WASH\LOCK\1/2
16	5000024	2	WASH\LOCK\1/4
17	6300057	1	TANK\FUEL\WELD\CHPPR
18	7501475	1	GAUGE\FUEL\SEND\WEMA\32"240-33OHMS
19	7501472	1	FUEL\CAP\DT-20


6300225

TANK\ASSY\TC15

NOT SHOW (WEAR PARTS)

4400127	1	FLTR\ELMT\OIL\MPFILTRI
4400066	1	GAUGE\FLTR\25PSI\1/8NPTF\COLOR CODED
4400148	1	FLTR\BRTHR\ASSY\10MIC\MPFILTRI
7501511	1	SEAL\SENDER\FUEL

GATHERING WINCH ASSEMBLY (OPTION)




GATHERING WINCH ASSEMBLY (OPTION)


ITEM	PART	QTY.	PART DESCRIPTION
1	1100297	1	SLING\2EYE\2PLY\2" X 6'
2	4800003	2	BOLT\HEX\3/8X1
3	4800010	6	BOLT\HEX\5/8X2
4	4800482	6	BOLT\CRG\5/8X1-1/2\NC
5	4900023	1	NUT\TPLCK\3/8\NC
6	4900110	6	NUT\FLG\SERR\5/8\NC
7	5000003	6	WASH\LOCK\5/8
8	5000019	2	WASH\LOCK\3/8
9	5800032	1	HOOK\SLIP\5/16\GR70\LATCH
10	5800035	1	WINCH\HYD\9000#
11	5800036	1	FAIRLEAD\RLLR\ASSY
12	5800041	1	LOCK\HMMR\CHAIN\WINCH\9/32
13	5800331	1	CABLE\1/4\ASSY\CHIPPER
14	6300107	1	SUPPORT\CABLE\WINCH\WELD
15	6300110	2	BRKT\SUPPORT\CABLE\WINCH
16	6300127	1	LEVER\CLTCH\WINCH
17	7500891	1	KNOB\CLAMP\3/8NCx1"STUD
	6300147		OPTION\WINCH\TC-15

REMOTE RADIO (OPTION)

ITEM	PART	QTY.	PART DESCRIPTION
1	5701007	1	TRANSMITTER\RADIO\MINI\KARTECH
	5700954		RADIO\MINI\KARTECH
NOT SHOWN			
	5701006	1	RECEIVER\RADIO\MINI\KARTECH
	5701075	1	CHARGER\BATTERY\REMOTE\TRANSMITTER




4000403 MANIFOLD VALVE ASSEMBLY



4000403 MANIFOLD VALVE ASSEMBLY

ITEM	PART	QTY.	PART DESCRIPTION
	4000403		VLV\MANIFOLD\ASSY\CHIPPER
1	4000346	1	VALVE\HYD\CART\COMP\150PSI
1 Seal	4000358		VALVE\SEAL\KIT\SZ10\2,3 OR 4 WAY
2	4000348	1	VALVE\HYD\SOL\24V\E70\DTZ
3	4000349	1	VALVE\HYD\CART\RELIEF\2500
3 Seal	7501370		SEAL\KIT\VLV\SZ8\2WAY
4	4000350	1	VALVE\HYD\CART\PILOT\110P
4 Seal	4000358		VALVE\SEAL\KIT\SZ10\2,3 OR 4 WAY
5	4000351	2	VALVE\HYD\CART\RELIEF\1000
5Seal	7501370		SEAL\KIT\VLV\SZ8\2WAY
6	4000352	1	VALVE\HYD\CART\PROPOR\6GPM
6Seal	4000358		VALVE\SEAL\KIT\SZ10\2,3 OR 4 WAY
7	4000353	1	VALVE\HYD\CART\3POS,5WAY\FLOAT;CENTER
7Seal	4000359		VALVE\SEAL\KIT\SZ10\5 WAY
8	4000354	1	VALVE\HYD\CART\3POS,5WAY\CLOSED;CENTER
8Seal	4000359		VALVE\SEAL\KIT\SZ10\5 WAY
9	4000355	2	VALVE\HYD\VCKR\3POS4WAY
			NOTE - There are (4) size -012 O-rings between 4000356 and main body
11	4000407	4	VALVE\HYD\SOL\24V\E10\DTZW/DIODE


MANIFOLD VALVE HYDRAULIC ASSEMBLY



MANIFOLD VALVE HYDRAULIC ASSEMBLY

ITEM	PART	QTY.	PART DESCRIPTION
1	3800477	3	FTG\3/4MORX3/4MJIC\ST
2	3800527	1	FTG\7/8MORX1-1/16MJIC\ST
3	3800537	2	FTG\3/4MORX3/4MJIC\90
4	3800631	4	FTG\9/16MORX9/16MJIC\ST
5	4000403	1	VLV\MANIFOLD\ASSY\CHIPPER


HYDRAULIC TANK ASSEMBLY



HYDRAULIC TANK ASSEMBLY

ITEM	PART	QTY.	PART DESCRIPTION
1	3700998	1	HOSE\HYD\1/2X62\3/4FJICSX3/4FJIC90 FROM CLUTCH SIDE TO TANK T
2	3700999	1	HOSE\HYD\1/2X48\3/4FJICSX3/4FJIC90 FROM SEQUENCE SIDE TO TANK T
3	3701514	1	HOSE\HYD\3/4X60\1-1/16FJICSX1-1/16FJIC90 FROM TANK OUT TO PUMP IN
4	3701001	1	HOSE\HYD\3/4X112\1-1/16FJICSX1-1/16FJIC90 FROM VALVE T TO FILTER
5	3800279	1	FTG\1-1/16MORX1-1/16MJIC\90
6	3800453	1	FTG\3/4MORX9/16MJIC\90
7	3800484	1	FTG\3/4FJICSX3/4MJICX3/4MJIC\RUN;TEE
8	3800490	1	FTG\3/4MOR\PLUG\HEX
9	3800527	1	FTG\7/8MORX1-1/16MJIC\ST
10	3800534	1	FTG\1-5/16MORX1-1/16MJIC\90
11	3800537	1	FTG\3/4MORX3/4MJIC\90
12	3800847	1	FTG\7/8MOR\PLUG\HEX
13	4000403	1	VLV\MANIFOLD\ASSY\CHIPPER
14	4400111	1	FLTR\SCRN\1-5/8MORX1-1-16FOR\10GPM
15	4400112	1	FLTR\HYD\RET\15GPM\TTF
16	7501337	2	CLMP\HOSE\CUSH\3/8

CLUTCH HYDRAULICS




ITEM	PART	QTY.	PART DESCRIPTION
1	O900150	1	CLUTCH\HPTO8\CHIPPER
2	3700997	1	HOSE\HYD\1/2X26\3/4FJCSX3/4FJIC90 FROM SEQUENCE T TOP TO CLUTCH TOP
3	3700998	1	HOSE\HYD\1/2X62\3/4FJCSX3/4FJIC90 FROM CLUTCH SIDE TO TANK T
4	3800477	1	FTG\3/4MORX3/4MJIC\ST
5	3800537	1	FTG\3/4MORX3/4MJIC\90

HYDRAULIC PUMP ASSEMBLY - CAT ENGINE

ITEM	PART	QTY.	PART DESCRIPTION
1	3700996	1	HOSE\HYD\1/2X23\3/4FJICSX3/4FJIC45 FROM PUMP TO SEQUENCE T FRONT
2	3701514	1	HOSE\HYD\3/4X60\1-1/16FJICSX1-1/16FJIC90 FROM TANK OUT TO PUMP IN
3	3800277	1	FTG\1-1/16MORX1-1/16MJIC\ST
4	3800328	1	FTG\7/8MORX3/4MJIC\ADPT
5	4200124	1	PUMP\HYD\89CID\CASAPPA


NOT SHOWN (WEAR PARTS)

4200161	PUMP\SEAL\KIT\4200142
4200168	GSKT\A-PAD\2BOLT\PUMP



SEQUENCE VALVE ASSEMBLY


ITEM	PART	QTY.	PART DESCRIPTION
1	3700996	1	HOSE\HYD\1/2X23\3/4FJICSX3/4FJIC45 FROM PUMP TO SEQUENCE T FRONT
2	3700997	1	HOSE\HYD\1/2X26\3/4FJICSX3/4FJIC90 FROM SEQUENCE T TOP TO CLUTCH TOP
3	3700999	1	HOSE\HYD\1/2X48\3/4FJICSX3/4FJIC90 FROM SEQUENCE SIDE TO TANK T
4	3701513	1	HOSE\HYD\1/2X87\3/4FJICSX3/4FJIC90 FROM SEQUENCE REAR TO VALVE P
5	3800477	1	FTG\3/4MORX3/4MJIC\ST
6	3800479	1	FTG\3/4MORX3/4MJIC\45
7	3800483	1	FTG\3/4MORX3/4MJICX3/4MJIC\RUN;TEE
8	3800816	1	FTG\9/16MORX3/4MJIC\90
9	4000403	1	VLV\MANIFOLD\ASSY\CHIPPER
10	4200139	1	VLV\SEQ\0-15GPM\PTTECH
11	4700777	1	CLMP\HOSE\1/2



TC-15 Tree Chipper

PARTS REFERENCE


FEEDWHEEL HYDRAULIC MOTORS



ITEM	PART	QTY.	PART DESCRIPTION
1	3701023	1	HOSE\HYD\1/2X54\3/4FJICSX3/4FJIC90 VALVE F TO MOTOR FEED BOTTOM TOP PORT
2	3701009	1	HOSE\HYD\1/2X48\3/4FJICSX3/4FJIC90 VALVE E TO MOTOR FEED TOP TOP PORT
3	3701010	1	HOSE\HYD\1/2X36\3/4FJICSX3/4FJIC90 MOTOR FEED BOTTOM BOTTOM PORT TO MOTOR FEED TOP BOTTOM PORT
4	3800328	4	FTG\7/8MORX3/4MJIC\ADPT
5	3800537	2	FTG\3/4MORX3/4MJIC\90
6	3800546	1	FTG\3/4MJICX3/4FJIC\90\SW
7	3900047	2	MTR\HYD\39.6C\DELTA\TAPERED
8	4000403	1	VLV\MANIFOLD\ASSY\CHIPPER


DISCHARGE HYDRAULICS

ITEM	PART	QTY.	PART DESCRIPTION
1	3701003	1	HOSE\HYD\3/8X39\3/4FJICSX9\16FJIC90 FROM VALVE A TO MOTOR SPOUT RH
2	3701003	1	HOSE\HYD\3/8X39\3/4FJICSX9\16FJIC90 FROM VALVE B TO MOTOR SPOUT LH
3	3800631	2	FTG\9\16MORX9\16MJIC\ST
4	3800675	2	FTG\7\8MORX3\4MJIC\45
5	3900032	1	MOTOR\HYD\22.6\H
6	4000403	1	VLV\MANIFOLD\ASSY\CHIPPER






HYDRAULIC CYLINDER ASSEMBLY



HYDRAULIC CYLINDER ASSEMBLY

ITEM	PART	QTY.	PART DESCRIPTION
1	3701006	1	HOSE\HYD\3\8X33\9\16FJICSX9\16FJIC90 VALVE D TO CYLINDER BOTTOM LIFT
2	3700653	1	HOSE\HYD\3\8X336\9\16FJICSX9\16FJIC90 VALVE C TO CYLINDER TOP LIFT
3	3800453	2	FTG\3\4MORX9\16MJIC\90
4	3800631	2	FTG\9\16MORX9\16MJIC\ST
5	4000403	1	VLV\MANIFOLD\ASSY\CHIPPER
6	4100262	1	CYL\HYD\2X12\1-1\4TUBE


GATHERING WINCH HYDRAULICS (OPTION)




GATHERING WINCH HYDRAULICS (OPTION)

ITEM	PART	QTY.	PART DESCRIPTION
1	3701007	1	HOSE\HYD\1/2X35\3/4FJICSX3/4FJIC90 FROM VALVE H TO MOTOR WINCH FRONT
2	3701008	1	HOSE\HYD\1/2X37\3/4FJICSX3/4FJIC90 FROM VALVE G TO MOTOR WINCH REAR
3	3800328	2	FTG\7/8MORX3/4MJIC\ADPT
4	3800477	2	FTG\3/4MORX3/4MJIC\ST
5	3800546	2	FTG\3/4MJICX3/4FJIC\90\SW
6	4000403	1	VLV\MANIFOLD\ASSY\CHIPPER
7	5800035	1	WINCH\HYD\9000#


5700991 HPTO HARNESS, chipper




ENGINE CONTROL PANEL FOR DURATECH HARNESS 5701143




5701024 MACHINE WIRING HARNESS




ELECTRICAL SCHEMATIC #1 (FOR S.N. UP TO 0010)




ELECTRICAL SCHEMATIC #1 (FOR S.N. 0011 AND UP)



ELECTRICAL SCHEMATIC #2




ELECTRICAL SCHEMATIC #3







DECALS



6500040



6500404



6500405




6500082



6500445



6500446



6500118



6500448




6500123



6500447



6500221



6500449




6500445



TC-15


6500516



6500245




6500455



6500339



6500253



6500373

DECALS

PART	QTY.	PART DESCRIPTION
6500495		DECAL\KIT\TC15
6500040	2	DECAL\WARN\SHIELD\PROT
6500082	2	DECAL\WARN\ROTATN;PART;>
6500118	2	DECAL\DNGR\OBJECTS;THROWN
6500123	1	DECAL\INFO\DIESEL;FUEL
6500221	2	DECAL\WARN\THROWN;OBJCTS
6500224	2	DECAL\LOGO\DURA\4-3/4\SIL
6500245	5.5 ft.	DECAL\TAPE\REFL\RED\WHT
6500253	1	DECAL\INFO\FLUID;LEVEL>
6500339	2	DECAL\WARN\PINCH;POINT
6500373	1	DECAL\INFO\BATT;DISC
6500404	1	DECAL\PNL\CNTRL\LEFT\CHIPPER
6500405	1	DECAL\PNL\CNTRL\RIGHT\CHIPPER
6500425	2	DECAL\WARN\FIRE\PREVENT
6500445	2	DECAL\DNGR\CHUTE\INFEED
6500446	2	DECAL\DNGR\LOCK\DISC\CHIPPER
6500447	2	DECAL\DNGR\TURNING\CHIPPER
6500448	1	DECAL\DNGR\FLUID\STARTING
6500449	1	DECAL\START\AUTOFEED
6500455	2	DECAL\LOGO\DURATECH\3"
6500478	1	DECAL\PATENT\US\7954736
6500516	2	DECAL\LOGO\TC15
6500529	1	DECAL\notice\switch\proximity
6500537	1	DECAL\BRAKE\ELEC\PULL\BUMPER
7500933		PAINT\BLUE\SPRAY\MET
7500984		PAINT\BLUE\GALLON

**PRODUCED UNDER
U.S. PATENT NO.
7,954,736**

6500478

NOTICE

Proximity Switch Check






5mm (3/16") clearance between sensor and magnet.

Sensor is properly rotated with the polarity of the magnet.

Yellow LED light will illuminate when sensor and magnet are aligned.

6500529


6500529

▲ WARNING	▲ WARNING	▲ WARNING	▲ WARNING	▲ WARNING
<p>Uncoupling will cause trailer to come loose from tow vehicle. You must:</p> <ol style="list-style-type: none"> CHECK that ball LOAD RATING is same as or greater than coupler LOAD RATING. CHECK that ball SIZE is same as coupler. CLOSE COUPLER CLAMP on ball. LIFT coupler upwards to test that it will not separate from ball. LOCK coupler clamp with pin or padlock. 	<p>ALWAYS use safety chains. Chains hold trailer if connection fails. You must:</p> <ol style="list-style-type: none"> CROSS chains underneath coupler. ALLOW slack for trailer to turn. ATTACH chain hooks securely to tow vehicle frame. 	<p>Trailer can roll if it comes loose. Electric safety brake applies when cable pulls pin out of switch box.</p> <ol style="list-style-type: none"> PULL hard to get pin out of switch box. CHECK brake by PULLING TRAILER with tow vehicle. ATTACH pin CABLE to tow vehicle so pin will be pulled out if trailer separates. Properly REPLACE pin in switch box. 	<p>Lights can prevent trailer from being hit by other vehicles. You must:</p> <ol style="list-style-type: none"> CONNECT trailer and tow vehicle electrical connectors. CHECK all lights: tail lights, turn signal, and brake lights. DO NOT TOW if lights are not working. 	<p>Tire, wheel or lug nut failure can cause loss of control. Before towing, you must CHECK:</p> <ol style="list-style-type: none"> Tire pressure and tread. Tires and wheels for damage. Lug nuts for tightness. <p>For new and remounted wheels, re-tighten lug nuts at the first 10, 25 and 50 miles of driving.</p>
 <p>Open clamp Closed clamp Pin or padlock in place Lift coupler to check</p> <p style="font-size: 0.7em;">© 2002 NATM</p>	 <p>ATTACH HOOKS TO TOW VEHICLE FRAME</p> <p>ENOUGH SLACK FOR TURNS</p> <p>CROSS CHAINS</p>	 <p>PIN PULLED OUT, ONLY TO TEST BRAKES</p> <p>ATTACH CABLE TO TOW VEHICLE</p> <p>PIN SWITCH BOX</p> <p>PIN SWITCH BOX (PIN STRONG AND STOWAGE)</p>	 <p>DISCONNECTED CONNECTED</p>	 <p>Lug Nuts TIGHT?</p> <p>Tires and Wheels OK?</p> <p style="font-size: 0.7em;">UT0023</p>


6500537

DECAL LOCATIONS

6500405



6500404





6500449


6500118

6500373

DECAL LOCATIONS



DECAL LOCATIONS



Send your comments to:


DuraTech Industries International, Inc.
P.O. Box 1940
Jamestown, ND 58402-1940

APPENDIX C SCHEMATIC FOLDOUTS





5701143 CHIPPER

5700932 LEFT CONTROL BOX









DVC 710 CONTROLLER
5700723

5701144 MACHINE PORTION



5700992 ONLY USED WITH KUBOTA ENGINE



ENGINE CONTROL PANEL

- 5B RED SCT 1
- 902 BLUE SCT 2
- 211 GREY SCT 4
- 101A VIOLET SCT 5
- 2A7A WHITE SCT 7
- 251-106 GREEN SCT 10
- 911 WHITE OR RED SCT 11
- 912 BLACK SCT 12

